

Operational Description of the equipment


1

- Insert software CD into a CD Rom Drive.
- Insérez le CD de logiciels dans un lecteur de CD-ROM.
- Die CD mit der Software in ein CD-ROM-Laufwerk einlegen.
- Inserte el CD del software a una unidad CD Rom.
- Inserire il CD del software nel lettore CD Rom.
- Steek de software CD in de CD Rom Drive.
- Introduza o CD de software no CD Rom Drive.



2

- Insert the USB dongle into a free USB port.
- Insérez le dongle USB dans un port USB libre.
- Den USB-Dongle in einen freien USB-Port einsetzen.
- Inserte el adaptador USB a un puerto USB libre.
- Inserire la dongle USB nella porta libera USB.
- Steek de USB dongle in de vrije USB poort.
- Insira o dongle de USB num porto de USB livre.



PRODUCT	Bluetooth Ver2.0+EDR USB
MODEL NO.	BT-MicroEDR2
POWER SUPPLY	DC 5 V, 0.1A
FREQUENCY BAND	2.401GHz ~2.483GHz
CARRIER FREQUENCY	2.402GHz ~2.480GHz
NUMBER OF CHANNEL	79
CHANNEL SPACING	1 MHz
RATED RF OUTPUT POWER	0 dBm
MODULATION TYPE	GFSK
DUTY CYCLE	50%
MODE OF OPERATION	duplex
BIT RATE OF TRANSMISSION	2.1 Mbps
ANTENNA TYPE	PCB print
ANTENNA GAIN	-2 dBi
OPERATING TEMPERATURE	-10~55°C
CHANNEL BANDWIDTH	1MHz

