




INPUT :



KEY1 (I/H):向前 (from 2.4G)

KEY2 (I/H):向後 (from 2.4G)

KEY3 (I/H):向左 (from 2.4G)



KEY4 (I/H):向右 (from 2.4G)

SPK (I/H):SPK (from 2.4G)



五款選擇方式:

OP2	OP1	OP0
1:0	0	0
2:0	0	1
3:0	1	0
4:0	1	1
5:1	X	X




<Reference Only>
<僅供參考>

Grossfield LTD. Room 02, 18/F, New Treasure Centre, 10 Ng Fong Street, San Po Kong, Kowloon, Hong Kong. TEL: (852) 27827530 FAX: (852) 23743607		
Title	WH1197	
Size	Document Number	Rev
A3	P200815	C3
Date:	Thursday, February 04, 2021	Sheet 1 of 4

燒錄腳

注意：

1. 燒錄IC的連接線勿超過20公分。
2. 使用內部震盪時，PRA0空接。



<Reference Only>
<僅供參考>



Grossfield LTD.

Room 02, 18/F, New Treasure Centre, 10 Ng Fong Street, San Po Kong, Kowloon, Hong Kong.
TEL : (852) 27827530 FAX : (852) 23743607

Title

WH1197

Size

A4

Document Number

P200815

Rev

C3

Date:

Tuesday, April 27, 2021

Sheet

1 of 1

1