

**IMPORTANT**  
**PLEASE DO NOT RETURN TO STORE**  
 If You're Having Trouble, We're Here to Help!



Call us 24/7 at 1-855-292-4087  
 E-mail us at support@alteclansing.com or visit us at alteclansing.com

**REGISTER YOUR PRODUCT**  
 To receive news, exclusive deals, OTA or firmware updates, warranty information and more please register your product at  
**alteclansingsupport.com**



**WELCOME** 😊  
 Thank you for purchasing an Altec Lansing product. It's our goal to make sure you are happy. Share your happiness with our customer concierge.



**ALTEC LANSING**



follow us @alteclansingofficial @alteclansing @alteclansingofficial

**12 Month Limited Warranty**  
 All Altec Lansing products come with 12 month limited warranty from the date of its original purchase


**24 Hour Customer Support**  
 We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1.855.292.4087 or e-mail support@alteclansing.com  
 www.alteclansing.com

**ALTEC LANSING**  
**JUST LISTEN.**




**HydraShock Everythingproof™ Wireless Speaker**  
**IMW1500**  
 QUICK START GUIDE


**In the Box**



IMW1500 HydraShock Everythingproof™ Wireless Speaker




Carry Strap




AC Adapter

**A Closer Look** 👁️



Volume Up/Next Track  
 Volume Down/Previous Track  
 Link Button  
 Answer & End Call/Voice Assistant  
 Color Change Button  
 Power Button




USB Port — AC Charging Port  
 Reset

**Charging** 🔋

● (red) = Charging  
 ○ (off) = Charging Complete


⌚ ≈3-4 Hours Full Charge



**Powering On/Bluetooth Pairing** 📶

**PRESS & HOLD 1-2 SEC** → **Pairing Mode**  
 Flashing Blue = Ready to Pair

→ **Solid Blue** = Paired




**Speaker Controls/Voice Assistant/Reset** 🎵

**PRESS**  
 + Volume Up  
 - Volume Down  
 ⏸ Play/Pause  
 📞 Answer & End Call  
 🗣️ To activate Voice Assistant (Siri or Google Assistant)

**PRESS & HOLD (2 sec)**  
 ⏻ ON /OFF  
 + Next Track  
 - Previous Track  
 📞 Reject Incoming Call  
 🗣️ Reset Incoming Call

**Reset- Press & Hold** 🗣️  
 Disconnect Bluetooth: Press and hold for five seconds and the speaker will beep.  
 Reset All connections: Press and hold for ten seconds and the speaker will power off



**True Wireless Pairing** 🎧

Turn on the first speaker and connect it with a Bluetooth compatible device.


Turn on the second speaker and press the **Link** button on that speaker.

Press & Hold 1-2 SEC → **Flashing green = Pairing**  
 Second Speaker

**Solid Green = Paired**


Press and hold the **Link** button for 2-3 seconds on the first speaker. The first speaker will now connect to the second so they both play in sync. The Link Buttons will illuminate green.  
 To end TWS press and hold the power button on the speaker.

There are two modes:  
 Mode 1: Dual Stereo, both play stereo for parties etc.  
 Mode 2: Wide Stereo, one plays left and the other right.  
 Briefly press the **Link** button to switch between the modes.




**Horizontal & Vertical Listening** 🎵

**Horizontal Mode**



The speaker will automatically switch modes based on its position (horizontal or vertical).

**Vertical Mode**




**Light Change Mode** 🌟

Press

To toggle between the different light modes:

- Multicolor slow transition
- Single color pulse to music
- Multi color pulse to music
- Single color slow fade
- Single color
- Multicolor cycle changed
- Multicolor fast changed with background color
- Multicolor slow fade
- Four color slow fade
- Four color rotation with pulse to music
- Four color rotation
- Off

Press & Hold the **Light** button for 1-2 sec to change the Strobe Light Modes.  
 \* off → Pulse to music → Blink → off \*



**FOLLOW US ON**  
 #myalteclansing

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
 - Reorient or relocate the receiving antenna.  
 - Increase the separation between the equipment and receiver.  
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 - Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.  
 This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Sakar International Inc.  
 195 Carter Drive  
 Edison, New Jersey 08817, USA  
 855-292-4087  
 www.alteclansing.com