

**IMPORTANT**  
**PLEASE DO NOT RETURN TO STORE**

If You're Having Trouble, We're Here to Help!



Call us 24/7 at 1-855-292-4087  
 E-mail us at support@alteclansing.com or visit us at alteclansing.com

**REGISTER YOUR PRODUCT**

To receive news, exclusive deals, OTA or firmware updates, warranty information and more please register your product at

**alteclansingsupport.com**



**WELCOME** 😊

Thank you for purchasing an Altec Lansing product. It's our goal to make sure you are happy. Share your happiness with our customer concierge.



follow us  
 @alteclansingofficial



follow us  
 @alteclansing



follow us  
 @alteclansingofficial

**12 Month Limited Warranty**

All Altec Lansing products come with 12 month limited warranty from the date of its original purchase


**24 Hour Customer Support**

We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1.855.292.4087 or e-mail support@alteclansing.com

www.alteclansing.com



**JUST LISTEN.**




**ROCKBOX XL2.0 WATERPROOF WIRELESS BOOMBOX WITH LIGHTING EFFECTS**


**IMW3100 QUICK START GUIDE**

IMW3100U-2390722

**In the Box**




**IMW3100 RockBox XL2.0 Waterproof Wireless Boombox With Lighting Effects**




AC Adapter


**A Closer Look**



**Charging**




4-5 Hours Full Charge  
 ● (red) = Charging  
 ○ (off) = Charged




**Powering On/Bluetooth Pairing**



PRESS & HOLD 2-4 SEC



Ready to Pair  
 Blue Slowly Flashing LED



**True Wireless Pairing**



Turn on the first speaker and connect it with a Bluetooth compatible device.

PRESS & HOLD 1-2 SEC



Turn on the second speaker and press the button on that speaker.

Flashing Green = Pairing



Press and hold the button for 2-3 seconds on the first speaker. The first speaker will now connect to the second so they both play in sync. The Indicator LEDs will illuminate green.


Solid Green = Paired



"To end TWS press & hold the power button on either speaker"

There are two modes:  
 Mode 1: Dual Stereo, both play stereo for parties etc.  
 Mode 2: Wide Stereo, one plays left and the other right. Briefly press the button to switch between the modes.


**Light Change Mode**



To toggle between the different light modes:

- Mode 1: Off
- Mode 2: Slow fade colour to colour.
- Mode 3: Colour change on beat.
- Mode 4: Colour change to the next one after three on/off fades.
- Mode 5: Single colour (customer can select colour by App).
- Mode 6: Colour bargraph.
- Mode 7: Colour Sweep.


**Controlling Music**



- PRESS**
- ▶ Play/Pause
  - + Volume Up
  - Volume Down
- PRESS & HOLD**
- ▶▶ Next Track
  - ◀◀ Previous Track

DBBS on/off: Press & hold " and + "

**Reset**



Press & Hold and -  
 Disconnect Bluetooth: Press & Hold for 1 seconds and device will beep.  
 Reset All Connections: Press & Hold for 10 seconds and device will auto power off.  
 All pairing information is reset.

Overall battery performance varies dependent upon use, settings and environmental conditions. For further information, please visit www.alteclansing.com

**FOLLOW US ON**



#myalteclansing

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Sakar International Inc.  
 195 Carter Drive  
 Edison, New Jersey 08817, USA  
 855-292-4087  
 www.alteclansing.com