

3 FAN SPEED CEILING FAN REMOTE CONTROLLER

OPERATION OF THE REMOTE CONTROLLER

A. Fan off Button :

To turn off the fan.

B. Light Button :

- Press and hold the light button more than one sec.
The light will change the brightness.
- Press the light button less than one sec.
The light will turn On or Off.

C. HI, MED, & LOW Buttons :

Press the button to turn On the fan and set the fan volume to strong or medium or low level.

