

# User manual

## HOW TO CARE FOR YOUR INTERACTIVE STORYBOOK AND ORNAMENT SET

- To replace the batteries, unscrew the compartment on the inside back cover of the book and insert new batteries.
- Remove the batteries before storing for an extended period of time.
- Store away from excessive heat and humidity.

Copyright © 2011 Hallmark Licensing, Inc.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions, (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus complies with Canadian ICES-003.

Published by Hallmark Gift Books,  
a division of Hallmark Cards, Inc.,  
Kansas City, MO 64141  
Visit us on the Web at [www.Hallmark.com](http://www.Hallmark.com).

All rights reserved. No part of this publication may be reproduced, transmitted, or stored in any form or by any means without the prior written permission of the publisher.

Editor: Meg Hilburn  
Art Director: Kevin Swanson  
Designer: Mark Voss  
Production Designer: Bryan Ring

ISBN: 978-1-59530-397-4  
QXG4729

Printed and bound in China  
MAY11

FCC ID: SQ9QXG4729  
IC:5768A-QXG4729  
Model: QXG4729

  
GIFT BOOKS



**User Manual (Model: QXG4729)**

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**For Book,  
FCC ID: SQ9QXG4729  
IC: 5768A-QXG4729**

**Responsible Party Information**

Hallmark Cards Inc.  
Keepsake Ornament Club Customer Service  
P.O. Box 419034  
Mail Drop 166  
Kansas City, Missouri 64141

PHONE: 1-800-HALLMARK (1-800-425-5627)