




Label Drawing



Although the FCC ID and IC No. are placed inside of the battery compartment, users will recognize the label when they put the battery into the device before starting to use it.

Label Location



シリアルシール貼付位置

Cereal label here.


国内向 シール：
For Japan.

SN.582E0000
Model: TR42

海外向 シール：

SN.682E0000
Model: TR42


For foreign countries.



認証シール貼付位置

Authentication label here.

ケース内部
Inside



シリアルシール貼付位置

Cereal label here.


国内向 シール：
For Japan.

SN.58300000
Model: TR45

海外向 シール：

SN.68300000
Model: TR45

For foreign countries.



認証シール貼付位置

Authentication label here.

ケース内部
Inside

