

SRQ-A004ZT TEST SETUP PHOTOS


RF TEST SET UP:




RF Conducted Test setup (BT/BLE/WIFI)




RF Conducted Test setup (WCDMA)




RF Conducted Test setup (LTE)




Spurious Radiated Emissions Test setup





Spurious Radiated Emissions Test setup




Conducted Emissions Test Setup (with charger)


EMC Test Setup




Radiated Emissions Test Setup (with laptop) (30-1000MHz)




Radiated Emissions Test Setup (with charger) (30-1000MHz)




Radiated Emissions Test Setup (with laptop) (above1GHz)



Radiated Emissions Test Setup (with charger) (above1GHz)





Conducted Emissions Test Setup (with laptop)



Conducted Emissions Test Setup (with charger)

SAR TEST SETUP






FLAT Section, Back

FLAT Section, Front



FLAT Section, Top



FLAT Section, Bottom



FLAT Section, Left



FLAT Section, Right

