



K87CA TEST SETUP


RF TEST SETUP




RF Conducted Test setup (BT/WIFI)




RF Conducted Test setup (WCDMA)




RF Conducted Test setup (LTE)



Radiated Emissions Test Setup



Radiated Emissions Test Setup




Radiated Emissions Test Setup

PART 15B Test Setup




Radiated Emissions Test Setup (with laptop) (30-1000MHz)



Radiated Emissions Test Setup (with charger) (30-1000MHz)




Radiated Emissions Test Setup (with laptop) (above 1GHz)



Radiated Emissions Test Setup (with charger) (above 1GHz)



Conducted Emissions Test Setup (with laptop)




Conducted Emissions Test Setup (with charger)

SAR TEST SETUP


(SAR Measurement)


| | |
|---|--|
|  |  |
| <p>Back (0mm with sensor on)</p> | <p>Top (0mm with sensor on)</p> |
|  |  |
| <p>Bottom (0mm with sensor on)</p> | <p>Left (0mm with sensor on)</p> |
|  |  |
| <p>Right (0mm with sensor on)</p> | <p>Spacers (Trigger distances-1 with sensor off)</p> |


(SAR sensor –Trigger distance)



(SAR sensor – coverage)







(SAR sensor –tilt angle)

