



Picture 16: Left Hand Touch Cheek Position




Picture 17: Left Hand Tilt 15 Degree Position



Picture 18: Right Hand Touch Cheek Position




Picture 19: Right Hand Tilt 15 Degree Position



Picture 20: Back Side, the distance from handset to the bottom of the Phantom is 15mm




Picture 21: Front Side, the distance from handset to the bottom of the Phantom is 15mm




Picture 22: Back Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 23: Front Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 24: Left Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 25: Right Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 26: Top Side, the distance from handset to the bottom of the Phantom is 10mm



Picture 27: Bottom Side, the distance from handset to the bottom of the Phantom is 10mm