

Thank you for purchasing this mobile. For the best performance, we recommend that you read the manual carefully.

R570

Quick Start Guide

Chapter 1 Phone overview


Main Display	160*128px
Phonebook capacity	SIM according to card's type; 100 in the mobile
Hands free	Supported
SMS	Supported
Incoming number Display	Supported
Alarm clock/Calendar	Supported
System Used	GSM900+DCS1800
Camera/ video record	Supported
MP3/Recorder	Supported
Call waiting	Supported
USB Mode/Memory Card	Supported (Micro-SD card) up to 16GB

Chapter 2 Key Instruction

Key Name	Function Description
Menu key	<ol style="list-style-type: none"> 1. To enter the main menu in idle mode 2. To answer a call
Send key	<ol style="list-style-type: none"> 1. Make or answer a call 2. Press Send key in standby mode to show the entire call log.
Left soft key	<ol style="list-style-type: none"> 1. To enter Menu in idle mode. 2. To execute the operation in left bottom of display
Right soft key	<ol style="list-style-type: none"> 1.To enter phonebooks in idle mode 2. To execute the operation in right bottom of display
End key	<ol style="list-style-type: none"> 1. End an active call or reject a call 2. Hold this key to power on/off 3. Exit form any interface to idle mode
Navigation keys	<ol style="list-style-type: none"> 1. Scroll the cursor up/down/left/right 2. Up key for user-defined shortcuts 3. Down key for Alarm 4. Left key for User profiles 5. Right key for Message
Number keys	<ol style="list-style-type: none"> 1. Enter numbers or characters while editing text 2. Press 0 key to insert a space while editing message, excluding the number input mode 1.Hold 0 key to turn on, turn off the flashlight 2.Press 1 key to insert common symbols while editing text, excluding the numbers input mode
#key / *key	<ol style="list-style-type: none"> 1.Press # key to change the input mode while editing text 2.Press * key to display the symbols window in the text input mode

Chapter 3 Insert SIM card

1. Power off the phone and remove the external power.
2. Take off the back cover and remove the battery of the phone.
3. Insert SIM card into the slot in the phone.



Chapter 4 Install and Remove the battery

The attached Li-ion battery can be used after unpacking. For the first three times, please use the charger to charge fully for new battery activation completely.

Install the battery

1. Put the battery in the battery compartment; note that the metal end of the battery should be firstly inserted.
2. Put on the back cover.



Remove the Battery

1. Take off the back cover.
2. Lift up the battery from the finger slot to remove the battery.



Chapter 5 Power on/Off your phone

1. Hold the End key to power on the phone. The phone will automatically search for the network.
2. When the phone is powered on, hold the End key to power off the phone.







Chapter 6 Charging Your Phone

1. Connect the phone charger to the wall socket/outlet.
2. Connect the charger to the device.



3. After charging completely (battery indicator shows fully), disconnect the charger from the device.

Chapter 7 Interface Icons

Icon	Description
	GSM system signal strength
	Profiles-General
	Bluetooth
	New message
	Power indicator
	Alarm

Chapter 8 Messages

Messaging is a service provided by your network provider; you may need to apply to your network operator before sending and receiving messages.

Write message:

[Text message]

You create SMS messages in this menu. You can:

Please click on the # key to switch the current input method.

Please click on the * key punctuation into the symbol.

Your phone supports the texts messaging function. If the message content is too long meaning more than the allowed 160 characters, it will be divided into two or more text messages.

In the options menu you can select the following:

- **Send to :** Edit the recipient, and then choose to send, edit recipient, remove the recipient, remove all the recipients, or save to the Drafts.
- **Input method :** You can use this menu to set the required input method and to insert symbols.
- **Insert template:** You can insert common language in a text message.
- **Advanced:** In this submenu you can insert number or insert name.
- **Save:** The edited message can be saved to the draft box through this menu.

Inbox

Select Inbox to view message received

Click the options you can:

View: check the received SMS

Reply: reply the sender via text message.

Call sender: You can call the sender's phone number

Forward: Forwards the original message or modified message to others selected or inputted contacts.

Delete: deletes the current message.

Delete all: delete all messages in the inbox.

Mark several: You can SMS bulk delete, copy, move.

Advanced: SMS can batch Copy, move and Use number, Use USSD, Use URL.

Drafts

View the draft you saved.

Outbox

View the unsent message.

Sent messages

View the sent message.

View: check the received SMS

Forward: Forwards the original message or modified message to others selected or inputted contacts.

Delete: deletes the current message.

Delete all: delete all messages in the inbox.

Mark several: You can SMS bulk delete, copy, move.

Advanced: SMS can batch Copy, move and Use number, Use USSD, Use URL.

SMS templates

You can insert common language in a text message.

SMS settings

Set the message configuration and can be view the memory information of message box.

SMSC number origin	Number retrieved from SIM
SMS - Type	Text
SMS – Validity period	The default 6 hours
SMS – Read receipts	Off

Chapter 9 Phonebook

When you enter phonebook press up/down key to select quick search, Search Contact, Add New Contact, Delete, phonebook Settings etc.

Press soft right key to enter phonebook in standby mode. Select a number, then you can view, send message, call, edit, delete, copy, Add to Blacklist, Mark several and phonebook settings.

For each telephone recording, press the "Options" button, you can do the following:

View: View the content of the telephone records.

Send SMS: to select contacts to send text messages.

Call: You can call the selected contact phone.

Edit: Edit the article calls.

Delete: delete the clause phone records from the phone book.

Copy: You can copy the phone records to the phone / SIM card, or copy records SIM card to the phone / SIM card.

Add to Blacklist: The contacts can be added to the blacklist

Mark several: You can mark off mass text messages and delete records marked contacts operation; wherein a tag number to send text messages to send up to 20 contacts.

Phonebook settings: You can view the storage capacity of the phone book, phone book inside the batch number to delete, copy and move.

Chapter 10 Call logs

Call history

1. Missed calls: Display the missed calls about the latest time and date, caller's number and calling times.

2. Dialed calls: Display the dialed calls about the latest time and date, caller's number and calling times.

3. Received Calls: Display the answered calls about the latest time and date, caller's number and calling times.

[View]: See the current record.

[Call]: Call the current number.

[Send text messages]: send text messages to the current record.

[Save to phonebook]: save the phone number to phonebook.

[Add to Blacklist]: Add the current to the blacklist.

[Edit before call]: on the current record for editing.

[Delete]: choose to delete the current record.

4. All Calls: With this feature, you can check recent missed calls, he had to answer the phone, dial the phone records had 20 words each record. After entering this function, press the up or down navigation key to select a phone number. Press the OK button to view the content of the telephone records.

5. Delete call logs: Respectively delete dialed calls, missed calls, received calls, phone records of all calls.

6. Call timers: You can view all of talk time.

Call settings

Call transfer and call waiting and other functions can be set in the menu.

[Call waiting] : Select the functions of open, close or inquire call waiting.

[Call divert] : Choose to open, close or enquire the call forwarding function.

[Call barring] : You can set Outgoing calls, Incoming calls and Cancel all constraints

[Line switching] : You can choose Line1 or Line2.

[Advanced Setting]: Set Blacklist, Auto redial, Auto Call Record, Call time display, Call time reminder, Reject by SMS, Vibrate when connect and Answer mode

2. Advance settings

1. **[Blacklist]:**

[Reject number in blacklist]: choose open or close this function

[Blacklist numbers]: Insert the blacklist number

2. [Auto redials]: Choose whether automatic redial will be implemented when the called party is in the busy or have no response.

3. [Auto Call Recording]: Switch on or off the function of auto recording

4. [Call time display]: Set the Call time display

5. [Call time reminder]: Set the Call time reminder

6. [Answer mode]: Choose answer mode, you can choose "Any key" or "Auto answer when headset mode".

Chapter 11 Settings

User Profiles

Your mobile provides several situation modes: General, Silent, Meeting and Outdoor.

1. Activate

Select a mode (except for Headset need plug in earphone), press the left software into select "activate" button, each scene mode (except for silent mode) can edit the look content

2. Customize

[Alert type]: Set alert type

[Ring type] : Set ring type

[Ringtone] : Set ring for incoming calls

[Ringtone volume]: Set the volume of incoming ring

[Message]: Set message ring

[Message volume]: SMS tone volume settings

[Keypad]: Set up the keypad tone

[Keystone volume]: Set the volume of Keystone

[System alert]: Setting the alarm system is turned on

3. Reset

Restore the User profiles settings to default.

Phone settings

1. Time and date

- ◆ Set home city: Choose the home city.
- ◆ Set time/date: Set the date and time.
- ◆ Set format: Choose the time and date format.
- ◆ Update with time zone: You can choose to open or close, the time will be different according to the time zone is changed after opening.
- ◆ Auto update time: After opening date will be automatically updated.

2. Language

Display Language for your mobile. The mobile phone in the English language by default

3. Pref. input method

Set the Pref. input method.

4. Display

- ◆ Wallpaper : Set the stand-by wallpaper.

- ◆ Auto keypad lock :choose the keypad lock for off, 15secs, 30secs, 1min, 5mins
- ◆ Power On display : Set switch-on animation.
- ◆ Power Off display : Set switch-off animation.
- ◆ Show date and time: Activate or deactivate displaying time and date in the stand-by screen.

5. Dedicated keys

You can select shortcuts inside menus.

6. Flight mode

In the "phone setting"- "fight mode" Choose the Flight Mode or Normal mode.

7. Misc. settings

Set the time limit for the back light of main screen to be off when there is no operation.

Security settings

SIM security:

Asked to enter the SIM card PIN code. After entering the correct before setting. If the SIM card is set to ON, each time you boot, you need to enter the PIN code, when entered incorrectly three times, it is required to enter your PUK (Personal Unblocking Key). PUK code is used to unlock and change the locked PIN code. If the PUK code is not provided or is lost, please contact your network operator.

Mobile Security Settings:

Use the phone lock operation; enter the password when opening or closing operation of the phone lock when the phone is turned off, you will be asked to enter the phone password at boot time. Phone password is 4 to 8 digits. The default password is "1122".

Change the password.

Privacy protection: After setting the privacy protection into different menus are required to enter a password

Network settings:

Network -> mode selection: 2G only.

Connectivity

1. Activate or deactivate the Bluetooth.

[Power] Activate the Bluetooth function.

[Visibility] Activate /Deactivate this function.

[My devices] Display the connected Bluetooth.

[Search audio device] Display the Bluetooth earphone and other device, and search the equipment.

[My name] View the Bluetooth name and can be edit the Bluetooth name.

[Advanced]

◆Audio path: To "Leave in phone" or "Forward to Bluetooth." Note: Due to this Bluetooth headset has the voice channel switching function, so when set to "remain in the mobile phone", click the multi-function Bluetooth headset button can also be connected to telephones, voice, but remain in the mobile phone side. Please refer to the specific operational guidelines of the Bluetooth headset, and recommended that users use standard headphones.

◆Storage: To preserve choice in the mobile phone or memory card to receive the document.

◆My address : Can be view the Bluetooth address.

2. Data accounts

Can account name, packet data connection point, user name, password, authentication type, SIM card options for editing and selection, you can also make advanced settings.

Restore factory settings

Input password recovery to before they leave the factory, the initial password is "1122".

Chapter 12 Multimedia

Camera

Open the camera via down key; Take the picture via menu key.

- 1. Switch to video recorder** : You can switch between camera and camcorder.
- 2. Photos** : View the photos that you saved.
- 3. Camera setting** : Set related parameters of the camera.
- 4. Image settings** : Set the size and quality of the photos.
- 5. Effect settings** : Set the special effects of photos.
- 6. Storage**: You can choose to save photos taken on your phone or T card.
- 7. Restore default** : Restore the camera settings to default.

Image viewer

View or modify photos saved in the album.

- 1. View**: View the selected images.
- 2. Send**: you can send the image by Bluetooth.
- 3. Use as**: use the phone as wallpaper in the Options.

4. Rename: Rename the current picture.

5. Delete: Delete the picture.

6. Storage: Select the position where image will be saved. Setting it in the Audio player Options.

7. Image information: Can be view the image information.

Video recorder

On the video interface, press up and down navigation keys to tune the focal length.

Note: Because the mobile memory capacity is limited, a T-flash card has to be inserted before you can save the video.

1.Switch to video recorder : You can switch between camera and camcorder.

2.Camcorder settings : Set the related parameters for the video camera.

3.Video settings : Set related parameters for the video clip.

4. Storage: Select the position where video clips will be saved.

Video player

Play user has recorded / downloaded video files; select a video according to the Options menu has the following functions:

1. Play: play a selected video file.

2. **Send:** send to other mobile by via Bluetooth.
3. **Rename:** change the file or folder name.
4. **Delete:** delete the file.
5. **Storage:** Select the position where video clips will be saved.

Audio player

Play user has recorded / downloaded Audio files; select an Audio according to the Options menu has the following functions:

1. **Play:** play a selected video file.
2. **Refresh list:** You can refresh the list.
3. **Settings:** Set the file to read the location of the playback mode, settings such as whether to open the background play.

Sound recorder

1. New record

Start recording.

2. List

View the recording of .avi files.

[Play] : Play a selected record.

[Rename] : Rename a selected record. Note : Renaming a record which has been set as incoming ring will make the settings back to defaults.

[Delete] : Delete a selected record.

[Use as] : Use the record as Ringtone.

[Send] : Send the record by BT.

3. Settings

Choose the Audio quality in the Settings.

Note : The recording time depends on the memory capacity of the mobile.

Chapter 13 Organizer

Calculator

The cell phone support continuous four mixed arithmetic operation and the operation is simple, practical and convenient.

Torch

You can open, close the flashlight.

You can open and close the torch in the idle interface through holding the key "0".

Calendar

To access the Calendar, press the left soft key. The first row displays year and month; the second row displays week; the middle part displays dates for a specific month; and the last row displays the two

soft keys. In the calendar mode, view the previous week by pressing the up navigation key and the next week by pressing the down navigation key; View the previous day by pressing the left navigation key and the next day by pressing the right navigation key. The selected date is displayed in deep color.

Tasks

You can add things to do in there recently, and which can modify the task reminder tones, modify the contents of the task, delete tasks and other operations.

Alarm

You can set 5 alarm times with this mobile. For each of them, you can set the alarm status to be open or not, set the alarm time and alarm frequency (once, daily or on several self-defined dates).

World clock

You can view the current time in different countries.

Chapter 14 File manager

It provides you the functions such as browsing media files, checking storage space and formatting function.

When browsing the media files, you can operate the selected files such as play, send, use as, new folder, rename, delete, mark several, copy, move, delete all files, details.

Chapter 15 Bowser

You can use the browser separately Browser, Facebook and other services.

Chapter 16 FM radio

This phone support the FM radio function.

[Channel list]: Set up the channel list and frequency.

[Manual input]: In put the frequency by manual.

[Auto search]: choose the "yes" then auto searching the channels.

[Settings]: Activate or inactivate the background and the speaker.

Chapter 17 Safety Information General Care

- If you want to clean your phone, please use clean fabric that is a bit wet or anti-static. Do not use harsh chemical cleaning solvents or strong detergents to clean it. Turn off your phone before you clean it.
- As your device can produce electromagnetic field, do not place it near magnetic items such as computer disks.
- Using the phone near electrical appliances such as TV, telephone, radio and personal computer can cause interference, which affects the function of the phone.
- Do not expose your device to direct sunlight or store it in hot areas. High temperatures can shorten the life of electronic devices.
- Prevent liquid from leaking into your phone.

Do not drop, knock or harshly treat your phone. Rough handling can break internal circuit boards.

- Do not charge the device without battery.
- Do not short-circuit the battery, as this can cause excessive heat and fire.
- Do not store battery in hot areas or dispose of it in a fire to avoid explosion.

- Store the phone out of the reach of little children. The phone may cause injury if used as a toy.
- Be aware of the usage limitation when using a mobile phone at places such as oil warehouses or chemical factories, where there are explosive gases or explosive products being processed, because even if your phone is in standby mode, it still transmits radio frequency (RF) energy; therefore power off your phone if required.
- Do not touch the antenna while calling. Otherwise it will affect the quality of calling and waste battery energy. The damaged antenna will cause slight burn while touching your skin.
- Do not put other things on the terminal to avoid overlaying radiator.
- Keep the antenna free from obstructions and position the antenna straight up. This will ensure best call quality.

General Guidelines

- If your device is lost or stolen, please report to your service provider or agencies of banning the use of your lost phone, which will protect you from economic losses resulted from unauthorized use. You need to provide the phone's ESN/MEID number labeled. You can see IMEI number after removing the battery. Please keep ESN/MEID number for future use.
- To protect your device from illegal use, please take the security measures as follows:
 - Set phone code of the phone.
 - Take it with you as you can.

Road Safety

- Pay attention to traffic safety.
- Do not use your device while driving.

Hospital Safety

- Some electronic devices are susceptible to electromagnetic interference sent by phone if inadequately shielded. Please use phone at least 20 cm or as far away as you can from TV set, radio and other automated office equipment so as to avoid electromagnetic interference.
- Operating this device may interfere with medical equipment like hearing aid and pacemaker. Please always keep the device more than 20 centimeters away from such medical devices when the phone is powered on. Do not carry the device in the breast pocket. Power the device off if necessary. Consult a physician or the manufacturer of the medical equipment before using the device.

Emergency Service

- On occasion of emergent calling, keep your phone in status of power on and in area of service. On the condition of standby, press the key to enter emergency phone number, and then press Call Key to make a phone call.

Third Party Equipment

- Please use original accessories or accessories that are authorized by the manufacturer. Using any unauthorized accessories may affect your devices' performance, and violate related national regulations about telecom terminals, or even endanger your body.
- Do not connect the phone with other unauthorized peripheral equipment.
- Do not attempt to disassemble the device and battery by yourself. Non-expert handling of the devices may damage them.

Vehicles Equipped with an Airbag

- Before making or answering a call, you should pay attention to the local laws about using wireless mobile phones and take them into account in practical use.
- Safety airbag, brake, speed control system and oil eject system shouldn't be affected by wireless transmitting. If you do meet problems above, please contact your automobile provider.
- Please power off your device when refueling your automobile, and so do the place where duplex wireless equipment is banned. Don't put your phone together with flammable or explosive items, as inner spark may cause fire.

Aircraft Safety

- Follow the restrictions in aircraft. Wireless devices can cause interference in aircraft.
- Please power off your device before taking on till landing. In order to protect airplane's communication system from interference, it is never allowed to use a mobile type device when it is in flight. Using a mobile phone before the plane taking off should get aircrew's permission according to safety regulations.

FCC Warning

§ 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAR Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.5 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.