

Photograph 1: SRX-SZKFULL (Front side)



Photograph 2: SRX-SZKFULL (Right side)



Photograph 3: SRX-SZKFULL (Back side)



Photograph 4: SRX-SZKFULL (Left side)



Photograph 5: SRX-SZKFULL (Top side)



Photograph 6: SRX-SZKFULL (Bottom side)



Photograph 7: Controller for SRX-SZKFULL (Opened state)



Photograph 8: Controller for SRX-SZKFULL (Back side)

