






8.3 EUT Inside View



8.4 Inside Antenna Connection




8.5 PCB Front Side View



8.6 PCB Back Side




8.7 125 kHz Antenna Top View



8.8 125 kHz Antenna Inside View



8.9 AC/DC Adaptor



8.10 Keypad /Relay Accessories