
Radiated Disturbance Setup – Horizontal Placement



Radiated Disturbance Setup – On Edge Configuration



 $Radiated\ Disturbance\ Setup-Vertical\ Configuration$

