

Quick Installation Guide

Brand: Dell

Product name: Dell PointBlank USB Dongle

Model no: DPB2701

DPB2701 is a 2.4G RF dongle designed to work with TI PointBlank system. It can receive coordinates from PointBlank projector and presents them as USB HID absolute mouse coordinates. DPB2701 is driver free for Windows XP, Vista and Win7.


Step 1 Install the Hardware

1. Insert the Wireless USB into the USB Port of your computer.
2. The system will automatically detect the new hardware.



Step 2 Verification

1. To verify if the device exists in your computer and is enable.
 - Go to start > Control Panel
 - System→Hardward→Device Manager→Keyboard
 - Expand the Keyboard category. If the “HID Keyboard Device” is listed here, it means that your device is properly installed and enabled.



Step 3 Install the Sofeware

- Insert the Wireless USB into the USB Port of your computer
- The USB will run automatically

**FCC ID : SUZ-PB2701**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications

Any changes or modification not expressly approved by the party responsible could void the user's authority to operate the device.

IC: 5923A-PB2701

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et*
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*