www.tuv.com

Test Report No.



Prüfbericht - Nr.:

14008086 001

Seite 11 von 15 Page 11 of 15



INTEX® OWNER'S MANUAL

Built-in Fast-FillTM Electric Pump

Model AP619RW

110 - 120 V~ 60 Hz 1.0 A

READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT

- Household use only.
- Always supervise children near the airbed. Children must not be left unattended when using the airbed.
- Keep the storage bag away from babies and children. The storage bag is not a toy. When not in use, fold the bag and put it away out of the reach of children.
- Do not stand on or jump on or use the airbed as a trampoline.
- Do not use on or near water. This is not a raft.
- Do not set up bed near stairs, doors, sharp edges or breakable objects.
- Make sure the area is flat, smooth, free of sharp objects that could puncture the bed and keep away from ledges.
- Keep pets away from the airbed. Pets may puncture the surface of the bed. Avoid sleeping on the edge of the airbed. Edges produce less support than the middle of the bed.
- Do not operate air pump for more than 5 minutes at a time. Let pump cool at least 15 minutes between uses.
- Unplug electrical power cord when not in use.
- Do not obstruct the air passage opening or insert any objects into the air passage opening.

 If the AC supply cord is damaged, it must be replaced by the manufacturer or its service agent in order to avoid a hazard.

FOLLOW THESE RULES AND ALL INSTRUCTIONS TO AVOID PROPERTY DAMAGE, ELECTRIC SHOCK, BURNS OR OTHER INJURY.

A CAUTION

To reduce the risk of electric shock, do not expose to rain. Store indoors.

SERVICING OF A DOUBLE-INSULATED PRODUCT:

SERVICING OF A DOUBLE-INSULATED PRODUCT:
In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor should a means for grounding be added to the product. Servicing of a double-insulated product requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to those parts in the product.

A double-insulated product is marked with the words "DØUBLE INSULATION" or "DOUBLE INSULATION" and with the symbol ...

INSTRUCTIONS

General

- This appliance has a polarized plug. It will only fit one way in a polarized outlet. If the plug does not fit, try reversing the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

 Locate the airbed with the backrest laying against the wall (for the airbed model with backrest only). Top cover can be detached and hand washed in a warm water solution with a mild detergent. Let the memory foam air dry but not in direct sunlight because the sun's ultraviolet rays will discolor the foam and will damage the foam's memory.

 No air pump maintenance is required.

- No air pump maintenance is required.

SAVE THESE INSTRUCTIONS

Appendix 5



TÜV Rheinland Group

www.tuv.com

Prüfbericht - Nr.:
Test Report No.

14008086 001

Seite 12 von 15 Page 12 of 15



FCC USER INSTRUCTIONS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to opreate the equipment.

SAVE THESE INSTRUCTIONS

Test Report No.





Prüfbericht - Nr.:

14008086 001

Seite 13 von 15 Page 13 of 15

PARTS REFERENCE






* Drawing for illustration only.


- **Part Descriptions:**
- 1. BUILT-IN AIR PUMP
- POCKET
- 3. HANDLE
- "2 IN 1" VALVES
- ZIPPER
- ZIPPER SLIDER
- REMOVABLE TOP
- 8. SHEET CORNER GUSSET
- 9. MEMORY FOAM
- 10. INFLATION MARK ()
- 11. INFLATION INDICATOR LIGHT
- 12. INFLATION BUTTON
- 13. DEFLATION INDICATOR LIGHT
- 14. DEFLATION BUTTON
- 15. DEFLATION MARK (பி) 16. AC LINE CORD 17. REMOTE CONTROL


- 18. INDICATOR LIGHT
- 19. BATTERY COVER

INFLATION

- 1. Make sure both "2 in 1" valves are securely closed. See Fig (1).
- 2. Plug the AC line cord into an AC electrical outlet. See Fig (2).







- FIG (2)
- 3. To inflate, press inflation button #12 on either built-in air pump or on remote control, remove finger
- 4. When the airbed is 80% inflated, press inflation button #12 (either on air pump or remote control) again to switch OFF. See Fig (3).






FIG (3)

SAVE THESE INSTRUCTIONS

Test Report No.





Prüfbericht - Nr.:


14008086 001

Seite 14 von 15 Page 14 of 15

- 5. Place the memory foam and removable top on the airbed. See Fig (4).
- 6. Slip the four corners of the memory foam into four sheet corner gussets. See Fig (5).
- Engage the cover zipper to the slider on the airbed and pull the zipper slider around the airbed counterclockwise. See Fig (6).







- 8. To complete inflation repeat step #3.
- 9. When the airbed is fully inflated to the desired firmness, press inflation button (either on air pump or remote control) again to switch OFF. See Fig (3). NOTE: Protection device will shut off the air pump after 5 minutes of continuous use.
- 10. Lay down on the airbed to test the firmness.
- 11. If the sleeping surface is too hard, adjust the firmness by pressing and holding the deflation button (#14 on either air pump or remote control). Air will exit through the air passage. See Fig (7). Release the deflation button when the desired firmness is achieved. If the airbed becomes too soft repeat steps #8 and #9.

IMPORTANT: Do not hold the deflation button (either on air pump or remote control) for more than 30 continuous seconds, as overheating will occur. Wait 10 minutes before using again to allow cooling.

12. Disconnect the AC line cord from the wall socket, place it and the remote control inside the pocket when airbed reaches the desired firmness.




FIG (7)



DEFLATION

- 1. Unscrew the exhaust valve caps from both "2 in 1" valves in a counterclockwise motion, See Fig (8). Air will exhaust from the portals.
- Begin rolling the airbed from the foot of the airbed towards the head of the airbed where the pump is located. Let the airbed stand with the valves open for a while to let any remaining air to flow out of the valves. See Fig (9). Make sure to return the exhaust valve caps back into the "2 in 1" valves. See Fig (1).



- Be sure the remote control is in the pocket. 3. Fold the airbed to fit into the storage bag.
- 5. Place airbed into a dry storage area.



FIG (9)

SAVE THESE INSTRUCTIONS

Test Report No.

Prüfbericht - Nr.:

14008086 001

Seite 15 von 15 Page 15 of 15



INFLATION OPTION

- 1. If electrical power is not available then a conventional foot or manually operated air pump can be connected to the "2 in 1" valve for inflation.
- 2. Pull the valve cap out from the bottom "2 in 1" valve (#4) and insert the air hose of a conventional foot or manually operated air pump. See Fig (10).
- 3. Start inflating with foot or hand pump, inflate to desired firmness.

INSTALL AND/OR REPLACE BATTERIES

- 1. Press and hold the triangular mark on the remote control cover, and slide the cover outward to open. See Fig (11). Replace the batteries if the remote control is not functioning.
- 2. Replace the old batteries with two 1.5 volt (size AAA) alkaline batteries.
- 3. Return the battery cover to the remote control.

STORAGE 1. Deflate the airbed following the "DEFLATION" instructions.

- 2. Make sure the airbed is clean and dry.
- 3. Fold the airbed loosely and avoid sharp bends, corners and creases which can damage the airbed.
- 4. Place the airbed inside the storage bag and store in a dry, cool storage location.
- 5. For long term storage, remove the batteries from the remote control.





@2004 Intex Recreation Corp., Long Beach, CA 90801-1440 USA ®™Trademarks used in some countries of the world by Intex Trading Ltd., under license from Intex Marketing Ltd. Made in China/ Fabriqué en Chine/ Hecho en China Consumer Service 1-800-234-6839

SAVE THESE INSTRUCTIONS