

# DT40 Quick Start Guide




3.01.50.01514

## Appearance and Buttons

Front view



Side View



Back View



## Package Contents




## Unpacking Instructions

SIM card, TF card installation method

Gently put the SIM card into the correct card slot in the correct direction for normal use. The TF card can be properly inserted into the correct card slot in the correct direction (as shown):

Note:

1. SIM card is NANO-SIM card
2. SIM card, TF card can be inserted into the normal position, can not be brute force



### Battery Installation



Install the battery in the orientation as shown above, then push the lock buckle to the right (lock).

### Power Options

- Power on: Press and hold the power button until device vibrates
- Shutdown: Press and hold the power button until the shutdown prompt appears. Click "Shutdown"
- Forced restart: Press and hold the power button for 10 seconds. Do not press the shutdown prompt. Device will restart.

## Charging Instructions

Connect one end of the USB cable to the adapter, and the other end to the device. Charging cradle is recommended for convenient charging.



电源适配器

Type C USB 数据线

## PC Connections

Connect device to PC using the USB cable provided. If additional driver is required, PC will automatically download from internet.

Once the USB port has been connected, drag the notification bar from the top of the screen to display the USB setting interface (Figure 2).






Figure 1

Figure 2



Tap this to activate developer menu shown in Figure 3  
Tap this to activate USB preference menu shown in Figure 4

Figure 3



Click this to switch on debug mode

## Precautions

1. Read all information in this guide before using the device to ensure safe and proper operation.
2. Please use the accessories that have been approved by this manufacturer and corresponds to this model. Use of any power source, charger, battery, etc. that has not been approved by this manufacturer may cause a fire, explosion, or other hazards.
3. Please use device and accessories within the specified temperature range. Equipment failure may occur when the ambient temperature is too high or too low.
5. Do not disassemble the product and its accessories. If the equipment or any of its components are not working properly, consult the after-sales service of the company promptly, or send the equipment to the after-sales service outlet for testing and maintenance.
6. If the battery displays abnormalities such as odor, heat, discoloration, deformation, and leakage during use or storage, immediately remove the battery from the charger or device and stop using it.
7. The battery is made from a flammable and explosive material. Do not disassemble, squeeze, drop and make any other destructive operations on the battery. Do not place the battery in high temperatures.
8. Disposal of used batteries is subject to local relevant documents or policies regarding disposal of used batteries.

Select this option to access device storage

Select this option to share the device data with the computer.

Choose this option to transfer images

Choose this option for charging the device




Figure 4

On Windows PC, go to "My Computer" . Click on "Removable Disk" to view and transfer device data.

Note:

1. When the DT50 as a SLAVE connect to PC, ' This device ' option will be automatically selected.
2. When the DT50 as a HOST connect to other devices, 'Connected device' will be automatically selected.

### Indicator

Battery		Full power
		Medium power
		Low power
Network signal		Good signal
		Unstable signal
	NONE	SIM card not installed
WiFi		SIM card error/no service
		WiFi on. No available wireless networks for connection
	NONE	WiFi switched off
NFC		NFC switched on

## Warranty Policy

Thank you for using Urovo intelligent terminal series products. In the situation of quality problems, which arise from raw materials or production processes, during normal use of purchased products, Urovo Technology Co., Ltd. will be responsible for free maintenance within one year from the date of purchase.

The company may provide repairs due to the user's failure to use the product according to the provided instructions of the product. However, corresponding service fee and component fee will be charged.

Warranty regulations:

1. Under normal circumstances, the warranty period of the device is 12 months (3 months for accessories), subject to the sales agreement.
2. During the product warranty period, under the normal use conditions (determined by our technical staff), the user will be entitled to a free warranty for damaged or faulty warranty parts.
3. During the warranty period, when the equipment fails, the equipment can be sent to Urovo Technology Co., Ltd. for maintenance at Beijing, Shanghai or Shenzhen. The freight will be borne by the sender.
4. During the warranty period, faults caused by repair, disassembly or modification of the product by a personnel other than our company, improper installation, improper use by the user (failure to follow instructions), serial number damage, accident or natural disaster, will not be covered under the warranty.
5. The warranty will expire immediately if any alterations are made to the warranty card.
6. Please show the equipment SN and purchase certificate for repair. The company reserves the right to interpret the above contents.

Place of Origin: Shenzhen Quality Inspector: 02

Shenzhen Urovo Technology Co., Ltd.  
Call: 400-888-6989 website: www.uovo.com

