




U200 USER MANUAL

Please read the user manual carefully before operation

II. Preface


Thanks for purchasing our U200 portable wireless stereo Bluetooth speaker. Please take the time to follow the instructions in this User manual carefully. If you have any queries, service hotline: + (86) 756-8322871

III. Standard Accessories



IV. Warnings and Cautions


- To reduce the risk of fire or electric shock, be sure the electrical circuits are not overloaded.
- To reduce the risk of electric shock, be sure not plug the adapter with wet hands.
- Unplug the power cable if your device is smoking or abnormal and seek professional help from your nearest service center; be sure not to detach the device yourself.
- To reduce the risk of fire or electric shock, do not expose this product to rain or other liquids.
- Do not touch the speaker grille or the surface of the speaker.
- The power cable and audio cable can not be twisted or fringed in case of short circuit.
- Do not place any naked flame sources, such as lighted candles, on or near the apparatus.
- Avoid charging the speaker under flammable storm weather.



V. Specifications

Channel	2.0
Bluetooth module	CSR
Bluetooth version	4.0/EDR
Interface	USB port, AUX in jack
Accessories	Charging cable, User manual, audio cable
Speaker	40mm TWT x 20mm
RMS	10W x 2
Bluetooth Distance	10M x 3M
Stability	78.4h
SN	>60dB
Distortion	100Hz-20KHz
Frequency response	50-3%V
Working voltage	3.3-4.2V
Working current	533mA
Battery	Touch button
Capacity	1000mAh
Charging time	3-4 hours
Playback time	Above 6 hours
Weight	45g
Size	128MM*75MM*55MM

VI. Speaker Overview



Remark: Please make sure your Bluetooth playback device supports Bluetooth 2.0/2.1 protocol.

VII. Operation Instruction

1. Charging

- Turn the ON/OFF button to ON to start the charging. Turn off the device to start normal charging.
- The red indicator will steadily on when charging and goes out after fully charged.
- Please charge the device before using.
- Please turn off the device when not in use to extend the lifespan.


2. Bluetooth Pairing

- Please make sure your device has sufficient power.
- Turn on the device. The blue indicator will flash to inform you Bluetooth is ready to be paired.
- Enable your Bluetooth of your playback device. Scan and select G500 U200 to pair the speaker. Input 000000 (four zeros) if required.
- The blue indicator will steadily on after pairing successfully.
- Now you can enjoy fantastic music.
- Press the touch button, volume up/down, play/pause to operate your speaker.




3. Hand free speakerphone

- Short press hand free key to answer the incoming call and short press again to hang up.
- Long press the hand free key to reject incoming call.



4. AUX in

- Use a 3.5mm audio cable to connect the speaker to another audio source; the Bluetooth audio streaming will be automatically interrupted as the speaker switches to AUX mode.
- Short press "M/F" key to switch to Bluetooth mode.



5. USB sound card

- Turn on your speaker
- Connect your speaker to the USB port of your PC. (One terminal connect to microphone, the other terminal connect to USB port of your PC). The device will install automatically.
- Then launch your player to enjoy fantastic audio. If there is no audio come out from the speaker, please select "USB Audio Device" as the default sound card in the property of audio settings.

6. NFC pairing

- Please make sure your playback device has NFC function.
- Enable your NFC
- Put your playback device close to "NFC" key area. Select "YES" when it popup whether to pair. (The paired devices will pair automatically for future use when the NFC function is enabled. Avoided to pair every time)
- The blue indicator will flash to inform you NFC pairing is successful.
- Put your playback device close to "NFC" key area to disconnect the two devices.

VIII. Troubleshooting

1. Unable to pair to device

Make sure your speaker is in pairing mode and follow the operation of Bluetooth pairing to pair again.

2. Speakers works with my smart phones but not my computer

The Bluetooth adapter in your computer needs to support the Stereo Bluetooth profile. Please check the property of the Bluetooth adapter in your computer. If the Bluetooth adapter is functioning properly, update the driver to the latest version. Please select "Bluetooth AV audio" in the property of audio settings as default audio output device.

3. The audio is on and off after pairing.

- Please make sure:
- There is no barrier between the two devices, e.g. wall, glasses.

* The Bluetooth distance is limited to 10 meters.

- Your playback device has sufficient RAM. We strongly suggest you to clean up your smart phone and tablet PC. To release enough space for your player. Or simply restart your smart phone and tablet PC.
- The distance between the two devices is kept a certain distance to a wireless WiFi or other 2.4GHz wireless devices.

Bluetooth® compatibility note: U200 can be compatible with most of Bluetooth devices with the different brand and models, but some individual Bluetooth devices may not be compatible. Please refer to the user manual for more details. For more information, please contact our technical customer service: 86-756-8322871.

IX. FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential environment.

This equipment does not emit radio frequency interference, and can receive radio frequency interference. If not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to you, you may wish to take the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Plug the equipment into a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

- FCC ID: starting statement. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure.

X. Statement

The G500 trademark and logo are registered trademarks of G500 Technology (Shenzhen) Co., Ltd. All other trademarks, logos or service marks are the property of their respective owners.

XI. Contact Us

G500 Technology (Shenzhen) Co., Ltd.
Add: the 10th Floor, First World Plaza, No. 1002 West Hough Road, Futian District, Shenzhen, China.
Tel: 0086-755-8326 6570
Fax: 0086-755-8325 5400
E-mail: sales@g500.com
Website: www.g500.com

XII. Limited Warranty

Your G500 U200 Bluetooth® speaker is covered by a limited warranty. It is backed by 1 year performance warranty against any manufacturing defect in material or workmanship from the date of original purchase. This warranty entitles the purchaser to a replacement of the product upon request.

- The warranty does not cover the damage caused by misuse, abuse or improper storage.
- The warranty does not cover the damage caused by natural disasters, consequential or other damages of any kind.

We reserve the right to change the specifications and design without notice.