

SYLVANIA

Bluetooth Speaker
MODEL NO: SP417
INSTRUCTION MANUAL



The picture is only provided for reference. Please refer to the actual unit!
SYLVANIA is a registered trademark of OSRAM Sylvania Inc. used under license.

Instructions for use

Please read all instructions carefully

Getting started
Remove the unit from the box
Remove any packaging from the product.
Place the packaging inside the box and store for safekeeping


In the box
Bluetooth Speaker
USB charging cable
3.5mm audio cable
Instruction Manual

Features
-Bluetooth wireless connection functionality
-Built-in rechargeable battery
-Volume adjustment
-Support USB/TF card
-Karaoke Function
-FM radio ,search and record
-Aux in jack

Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not put objects into any of the openings. Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use Keep the unit out of reach of children
- This product is not a toy
- Do not use abrasive cleaning solvents to clean
- To minimize the risk of fire or electrical shock, avoid operating in wet conditions such as rain or humidity
- Do not operate around water (e.g. bathroom, swimming pool etc.)
- Do not expose to excessive heat such as sunshine, fire etc
- Never immerse the unit in water or any other liquid for cleaning purposes

Produce Diagram



TF slot:	Used to read the Mp3 files In FAT 32 format with maximum size of 32GB
USB slot	Used to read the Mp3 files In FAT32 format with maximum size of 32GB
◀◀	Under FM/USB/TF/Bluetooth mode, short press to move to previous channel/track
▶▶	Under USB/TF/Bluetooth mode, short press for play and pause; Under FM mode, Short press for automatic search.
▶▶	Under FM/USB/TF/Bluetooth mode, short press to move to next channel/track
Mode	Mode shift button. Short press and shift to Bluetooth/FM/AUX mode. Default mode will be wireless connection mode NOTE: Long time press to turn off the LED light
DC-5V	One end of the cable should be inserted In DC 5V, another end with USB jack be inserted In USB port of the PC or other charging device with standard DC5V jack. The indicate LED is on when charging.
Aux	Audio Input jack when connect Enable the sound source connection active devices(PC, digital media player, mobile phones and other audio-visual products)
MIC	Microphone jack
VOL Knob	Control the music volume

INSTRUCTION FOR USE

Charging the speaker
This unit has a built in rechargeable battery. Before using it for the first time we recommend you use the USB cable to charge the battery fully. Connect USB charging cable to the USB port or USB wall charger(Not included.)And connect other side to the USB charging slot of the speaker. The battery charging LED indicator illuminates while the speaker is being charged. When the battery is fully charged, the red LED indicator will be OFF.

Pairing your device with Bluetooth speaker
Pairing the Bluetooth with Bluetooth devices (phone or music device).
Turn the VOL knob to turn the speaker ON and the Bluetooth mode will on automatically, you will hear a tone.
Place the speaker and Bluetooth device (phone or music device)so that they are no further than 20 feet apart:
Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.

Once you have activated Bluetooth on your device, select the pairing name "Sylvania SP417" from the list of available Bluetooth devices.
If required, enter the password 0000 to confirm to pairing.
Once paired successfully, you will hear a voice indicating pairing successful.You can now start to use the speaker.
Once you have paired the speaker with a device, the speaker will remember this device and will pair automatically when the devices Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.
The speaker will attempt to automatically connect to the last device it was paired with when Bluetooth mode turns on. If you want to pair it with a new device, please turn off your last Bluetooth device(phone or music device) then use your new device to search and select the pairing name.
Once the speaker is paired with your device the music will transmit directly to the speaker. Please refer to your devices user manual for further information.

Function Summary

Listening to Music
Once the speakers are paired with your device you can stream music wirelessly through the portable speaker. Select the track you wish to listen to and it will be streamed to your Bluetooth speaker, and you can use your device to control the Volume and skip tracks.

USB/ TF card playback
After the speaker is turned on, insert the USB/TF card to the slot will start to play the music automatically, and the Bluetooth mode will be disconnect.

Using AUX-in
After the speaker is turned on, pressing the M button can switch to Aux mode and connect one end of the 3.5mm audio cable into AUX in jack, the other end of the cable to connect MP3/Smart phone / iPhone to play music.

FM radio
After pressing M button to change to FM radio status,press ▶▶button to search channel automatically. This operation will scan all FM stations and pre-record them to memory. The scan procedure will take several minutes to complete and should not be interrupted.

Once completes , short time press the "◀◀" or the "▶▶" button to switch to last or next record frequency .

KARAOKE function
Inserting the microphone into speaker MIC port

Please Note
•Not all mobile phones support all the functions listed above Please refer to your cell phone s user's manual for further information
•Certain functions and indication tones may vary depending on your mobile phone.

Cleaning & Maintenance
Turn OFF the speaker if it is left unattended and before cleaning.
Never immerse the speaker into water and please use a dry cloth for cleaning.

Storage
•Turn OFF the power when you not in use, clean and store safety.

Specifications

Bluetooth specification	Bluetooth V4.2
Operating distance	10 meters(max.)
Speaker drive size	2 X 4 inch
Speaker power	5W+5W
Frequency response	100Hz-20KHz
Signal to noise ratio	≥ 85dB
Built-in battery	3.7V / 1200mAh
Charging time	About 3 hours
Working time	About 1.5 hours

Note: Battery life & charging time may vary based on usage & types of devices used.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
-Consult the dealer or an experienced radio/TV technician for help
This device has been evaluated to meet general RF exposure requirement. The device can be used in portable condition without restriction.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received including interference that may cause undesired operation.
For service assistance and product information, please call: 1-800-968-9853.
Curtis International Ltd.
7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3