

Shenzhen KingBoard Technology Co., Ltd.

FM TRANSMITTER

KD-204

Statement item:

Firstly, thanks for you to choose our car MP3 digital product.

To use this product rightly, please read the manual before usage.

For the sake of the better service, the contents of the user's manual may be changed.

Change about performance and function of products will make no further notice.

Set up:

※Insert this FM transmitter into your vehicle's cigarette lighter or power port

※Tune on your radio to a desired FM frequency, than match that same frequency on the player by using the button on the unit or on the remote control

※Plug USB disk into this product , it will play and transmit the MP3 file automatic.

※Plug SD/MMC memory card into this product , it will play and transmit the MP3 file automatic

※This product support another devices, normal MP3/MP4, CD, DVD player...Using the 3.5mm to 3.5mm audio cable provided, Plug one jack into this transmitter, The other enter into normal MP3/MP4, CD, DVD player..., It will play and transmit the songs from the MP3/mp4, CD, DVD player And this state, All function will now need to be controlled on the device, Not this transmitter or its remote control, Enjoy!

Operation guide:

Operation guide	FM Transmitter	Remote control
1. How to play and stop	Press "▶ " button: play the music Scond press "▶ " button: Stop	Play "▶ " button
2. How to adjust the Volume	Press "▶▶ " button long time: Increase the Volume Press "◀◀ " button long time: Decrease the Volume	Press "VOL.+" button: Increase the Volume Press "VOL.-" button: Reduce the Volume
3. How to change the frequency	Press the "▶▶ " button: Increase the frequency Press the "◀◀ " button: Decrease the frequency	Press "CH+ " button: Increase 0.1MHZ Press "CH-" button: Reduce 0.1MHZ Pr press the "CH" then press the number of frequency what you desired ,2 secounds later . it will be changed automatically
4. How to choose music	Short press "▶▶ " button : Play the next song Short press "◀◀ " button: Play the previous song	Press the "▶▶ " Button: Play the next song Press the "◀◀ " Button: Play the previous song Under MP3 mode, press FOL- can play the songs from last fold , press FOL+ can play the songs from previous fold .
5. How to set EQ	Nonsupport	Press "EQ" button to switch your favorite EQ

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.