




Imperial Video Decoder



This set includes:

- 1 Imperial Decoder
- 1 Base
- 1 Track Clamp
- 1 RCA Cable
- 2 Star Wars® Dag Racers

IMPORTANT! ADULT SUPERVISION AND ASSISTANCE MAY BE REQUIRED ON ASSEMBLY

Unpacking your DaGeDar™Star Wars® Imperial Video Decoder

Remove all contents from package and discard any rubber bands, wire ties or other packaging materials that are not part of the product.

- Please retain these instructions as they contain important information.
- Read all of the instructions before assembling your set.
- Some adult assembly is required.

Video Display System:

The video display system in the Imperial Video Decoder works with all Star Wars® Dag Racers. It reads the secret ID code inside each ball and displays video specific to that ball.

To see your Star Wars® Dag Racers on screen, place racers into the cradles on front of unit then press and hold the push button until the display turns on. The Video Decoder will play animated ball videos side by side on screen.



If the Decoder detects a special ball combination, it will display a bonus video! Not all Star Wars® Dag Racer combinations unlock bonus videos. Try your own combinations to see if you can find the special bonus videos.

After the video is done, the screen will power down and the decoder will go into low power sleep to save batteries.

Auxiliary TV output:

Use the TV output to display video on television instead of the LCD display. Connect one end of cable provided to TV output on side of Video Decoder and the other end to the Yellow, White and Red composite video inputs on your television.

Check the name or channel number of the composite video input on your television, as this will help when you go to select proper input channel.



Now activate Video Decoder by pressing the pushbutton for 2 seconds then cycle to the correct input channel by pressing the Input select on your TV or remote. Some common input select buttons are Input, Input Select or TV/Video. For more information on changing input channel to your television, consult your television user's manual.

Important: Remember that the Imperial Video Decoder goes into low power sleep mode after its video is complete. The television will not detect a video signal when Decoder is in sleep mode.

Changing the Batteries

Adult supervision is required.

- A. Unscrew the battery hatch on the bottom of the Imperial Video Decoder.
- B. Install three AA batteries matching the polarity shown inside the battery compartments. Be sure the batteries are firmly seated.
- C. Replace the hatches and screw snug.



Requires 3 AA Batteries Not Included

DaGeDar™Star Wars® sets are made to work with DaGeDar™Star Wars® balls.


For more information on DaGeDar™Star Wars® balls and accessories please go to: www.dagedar.com/starwars

The Imperial Video Decoder can be used as a standalone desktop display using ball tray provided or as a start gate by attaching to any two lane Dagedar Star Wars® track (sold separately).

Desktop Display



Start Gate



When using the Video Decoder as a start gate, press the release lever on the back of unit to drop the balls onto the track and watch them race. Batteries not included

www.dagedar.com/starwars

For Questions and Comments please call: 1 800 225 9319



©2012Cepia LLC.
121 Hunter Ave.
St. Louis Missouri 63124
Made in China



WARNING:

All rubber bands and wire ties, as well as tags, are not parts of this toy and should be discarded for your child's safety. Colors and contents may vary from those shown on the package.

Printed in China
U.S. and Foreign patents pending