






Droid Display Decoder

4+



Works with all Star Wars® Dag Racers
Batteries Not Included



Unpacking your DaGeDar™ Droid Display Decoder

Remove all contents from package and discard any rubber bands, wire ties or other packaging materials that are not part of the product.

- Please retain these instructions as they contain important information.
- Read all of the instructions before assembling your set.
- DaGeDar™ Droid Display Decoders come in different styles and colors and may differ from the one shown on this instruction sheet.
- Batteries are not included.
- Balls are sold separately.

DaGeDar™ Droid Display Decoders work with all Star Wars® Dag racers only. For more information on DaGeDar™ balls and accessories please go to: www.dagedar.com/starwars

BATTERY INFORMATION

- Always replace used batteries with fresh alkaline batteries. Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Do not mix old batteries with new, do not mix alkaline with standard carbon zinc or rechargeable nickel cadmium batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged. Rechargeable batteries are only to be charged under adult supervision.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

CAUTION • Do not dispose of batteries in fire.

- Discard old batteries in accordance with local regulation.
- Do not store loose batteries.

Claim: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. This Class B digital apparatus complies with Canadian ICES-003. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Requires 3 AAA Batteries (not included)



Changing the Batteries

Adult supervision is required.

- Unscrew the battery hatch on the bottom the Droid Display Decoder.
- Install three AAA batteries matching the polarity shown inside the battery compartment. Be sure the batteries are firmly seated.
- Replace the hatch and screw snug.

www.dagedar.com/starwars

For Questions and Comments please call: 1 800 225 9319



©2012Cepia LLC.
121 Hunter Ave.
St. Louis Missouri 63124
Made in China



WARNING:

All rubber bands and wire ties, as well as tags, are not parts of this toy and should be discarded for your child's safety. Colors and contents may vary from those shown on the package.

Printed in China
U.S. and Foreign patents pending;