





EGF0100-Mainboard location in unit.




Backup battery

EGF0100-Mainboard – Top side




Main battery connector

EGF0100-Mainboard – Bottom side



EGF0400-Ethernet-WIFI-BT PCB location in unit.


EGF0400-Ethernet-WIFI-BT PCB Top side.



Bluetooth antenna.

WIFI antenna.


EGF0400-Ethernet-WIFI-BT PCB Bottom side.








EHC1600-SAM\_MSK PCB-Top side.




EHC1600-SAM\_MSK PCB-Bottom side.






FCE056-SMART CARD READER-ANTENNA PCB-location in unit.

FCE056-SMART CARD READER-ANTENNA PCB-Top side.




FCE056-SMART CARD READER-ANTENNA PCB-Bottom side.






EHC1700-Fingerprint PCB-location in unit.

EHC1700-Fingerprint PCB-Top side.



EHC1700-Fingerprint PCB-Bottom side.









EGF0200-KEYBOARD PCB-location in unit.



EGF0200-KEYBOARD PCB-Top side.



EGF0200-KEYBOARD PCB-Bottom side.



EGF0400-WIFI\BLUETOOTH\ETHERNET PCB

EGF0100-MAINBOARD


LCD side

Wifi and BT combo module Top side with shielding





Wifi and BT combo module Top side without shielding



Wifi and BT combo module bottom side

