


AHN90-01-Mainboard location in unit.




F10091-CF WIFI module (8900VS)  
or  
F10092- SDIO WIFI module (8900VM)

F10101-Flash IDE 4GB (8900VS only)

F10094-CPU module (8900VS)  
or  
F10093-CPU module (8900VM)

F10107-  
850/900/1800/1900/2100 MHZ  
MULTI-BAND MODULE


AHN90-01-Mainboard-top side




F10104-Bluetooth module

AHN90-01-Mainboard-bottom side


I10115-Microcontroller





AGE20-Secondary battery interconnect PCB location in unit.




AGE20-Secondary battery interconnect PCB-top & bottom view



AHN02-01-Interconnect PCB location in unit.



AHN02-01-Interconnect PCB-Top & Bottom view.






AGE11-02-8900V Keyboard PCB location in unit.



AGE11-02-8900V Keyboard PCB-Top & Bottom view.






AHN62-GPS interconnect PCB location in unit.




AHN62-GPS interconnect PCB-Top & Bottom view.



AHN90-01-SD/SIM socket PCB location in unit.




AHN90-01-SD/SIM socket PCB SD & SIM side.





AHN61-USB CAMERA PCB location in unit. (8900VS)



AHN61-USB CAMERA Top & Bottom PCB. (8900VS)



AHN60-USB CAMERA ASSY. (8900VS)




AHL61-CAMERA PCB location in unit. (8900VM)



AHL61- CAMERA Top & Bottom PCB. (8900VM)




AHL60- CAMERA Top & Bottom ASSY. (8900VM)







AGE31-RJ45 connector location in unit.



AGE31-RJ45 connector views.

