



OFF-ROAD SAFARI
RADIO CONTROLLED ALL-TERRAIN VEHICLE

EXTRA-BRIGHT LED LIGHTS
FOR RACING AT NIGHT!

SPRING-LOADED SHOCKS
FOR OFF-ROAD ACTION!

BLUE HAT
FOR COMPETITIVE RACING!

TWO FREQUENCIES FOR COMPETITIVE RACING!

WIRELESS RC ACTION!

AGES 6+

BATTERY OPERATED RACING VEHICLE

WARNING!
CHOKING HAZARD - Small parts. Not for children under 3 years.

CAUTION!
CONTAINS BATTERIES. READ INSTRUCTIONS CAREFULLY.

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OFF-ROAD SAFARI
RADIO CONTROLLED ALL-TERRAIN VEHICLE

EXCITING RC FOR DRIVING IN THE

- Full-Function Wireless Remote Control
- Spring-Loaded Shock Suspension
- Available in 2 Frequencies for Competitive Racing

Fast-Paced Racing plus LED Lights for Driving in the Dark

Full-Function Wireless Remote Control

Spring-Loaded Shock Suspension and Knobby Tires for All-Terrain Racing

Available in 2 Frequencies for Competitive Racing

OFF-ROAD SAFARI


RADIO CONTROLLED ALL-TERRAIN VEHICLE

BATTERY INSTALLATION

The vehicle requires 2 "AA" 1.5V batteries (not included). The controller requires one 9V battery (included). When charging batteries, adult supervision is required. Use alkaline batteries for the best performance.

- Carefully remove items from the package.
- Locate the battery door on the bottom of the vehicle. Using a Phillips screwdriver, remove the screw.
- Pull the latch on the door to the left and lift up to access the battery compartment. Insert 2 "AA" batteries while observing the correct polarity (Fig. 1).
- Release the battery compartment door.
- Slide the battery door on the back of the controller down to open.
- Insert one 9V battery while observing the correct polarity (Fig. 2).
- Release the battery compartment door.
- Switch both the vehicle and controller power switches to the "ON" position.
- Adjust the steering alignment lever located on the bottom of the vehicle (between front wheels) if the vehicle does not run straight when moving forward.

NOTE: For best operation, use the vehicle on a hard surface.



SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Read and obey all rules when operating your vehicle.
- Do not submerge vehicle or controller in water.
- Never operate your vehicle on the street or highway.
- Adult supervision is recommended when operating this vehicle.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate your vehicle in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your vehicle into furniture, objects or hard surfaces, as this will cause damage to both the vehicle and the vehicle.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the vehicle is switched to "ON".
- Do not use vehicle or controller near sources of heat or under direct sunlight for long periods of time.
- Do not leave vehicle or controller unattended overnight. Damage is harmful to interior components.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

BATTERY WARNING:
Do not use old and worn batteries. Do not mix old and new batteries. Do not use damaged, recharged (rechargeable), or rechargeable (nickel-cadmium) batteries. Do not use batteries with the wrong polarity. Do not connect or disconnect batteries according to the instructions. Do not touch the terminals of the battery. Do not use the battery for anything other than the intended purpose. Do not use the battery for anything other than the intended purpose. Do not use the battery for anything other than the intended purpose.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

2906082 (32900)



DX2015A
Toy RC 4x4

OFF-ROAD SAFARI
RADIO CONTROLLED ALL-TERRAIN VEHICLE

EXTRA-BRIGHT LED LIGHTS
FOR RACING AT NIGHT!

SPRING-LOADED SHOCKS
FOR OFF-ROAD ACTION!

BLUE HAT
FOR COMPETITIVE RACING!

TWO FREQUENCIES FOR COMPETITIVE RACING!

WIRELESS RC ACTION!

AGES 6+

BATTERY OPERATED RACING VEHICLE

WARNING!
CHOKING HAZARD - Small parts. Not for children under 3 years.

CAUTION!
CONTAINS BATTERIES. READ INSTRUCTIONS CAREFULLY.

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OFF-ROAD SAFARI
RADIO CONTROLLED ALL-TERRAIN VEHICLE

EXCITING RC FOR DRIVING IN THE

- Full-Function Wireless Remote Control
- Spring-Loaded Shock Suspension
- Available in 2 Frequencies for Competitive Racing

Fast-Paced Racing plus LED Lights for Driving in the Dark

Full-Function Wireless Remote Control

Spring-Loaded Shock Suspension and Knobby Tires for All-Terrain Racing

Available in 2 Frequencies for Competitive Racing

OFF-ROAD SAFARI
RADIO CONTROLLED ALL-TERRAIN VEHICLE

EXTRA-BRIGHT LED LIGHTS
FOR RACING AT NIGHT!

SPRING-LOADED SHOCKS
FOR OFF-ROAD ACTION!

BLUE HAT
FOR COMPETITIVE RACING!

TWO FREQUENCIES FOR COMPETITIVE RACING!

WIRELESS RC ACTION!

AGES 6+

BATTERY OPERATED RACING VEHICLE

WARNING!
CHOKING HAZARD - Small parts. Not for children under 3 years.

CAUTION!
CONTAINS BATTERIES. READ INSTRUCTIONS CAREFULLY.

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OPERATING CONTROLS

LEFT JOYSTICK: FORWARD & REVERSE
RIGHT JOYSTICK: LEFT & RIGHT

OFF-ROAD SAFARI
RADIO CONTROLLED ALL-TERRAIN VEHICLE

EXCITING RC FOR DRIVING IN THE

- Full-Function Wireless Remote Control
- Spring-Loaded Shock Suspension
- Available in 2 Frequencies for Competitive Racing

Fast-Paced Racing plus LED Lights for Driving in the Dark

Full-Function Wireless Remote Control

Spring-Loaded Shock Suspension and Knobby Tires for All-Terrain Racing

Available in 2 Frequencies for Competitive Racing

© 2015 Mattel. "SXS" and "Blue Hat" are trademarks of Mattel. "SXS" and "Blue Hat" are registered trademarks of Mattel. "SXS" and "Blue Hat" are registered trademarks of Mattel. "SXS" and "Blue Hat" are registered trademarks of Mattel.