

ART DEPARTMENT			
Job # / Filename	20160420_BMC_C01VengeanceCar_ChargeSheet_01	Product Line	Blue Hat Toy Company
Developer	Brand Manager	Finished Size	20cm W x 23.5cm H x 28.5cm D
Draw Team	Line Navigator	Color	CMYK Process
File Format	Adobe Illustrator CC (Swatch) (CMYK)	Print Date / User	Comments
Printing Process / Finishing	Glaze PP Coating		

- Hyper-Speed Racing On Any Terrain
- Oversized Knobby Tires And 4-Wheel Suspension
- Full Function Wireless Remote
- Available In 2 Frequencies For Competitive Racing



# VENGEOANCE



# VENGEOANCE

RADIO CONTROLLED ALL-TERRAIN RACE CAR



AGES 6+

- BOX CONTAINS THE FOLLOWING FREQUENCY:
- 27 MHz
  - 49 MHz

**BATTERY OPERATED PLAY VEHICLE**  
AGES 6 AND UP

**WARNING!**  
CHOKING HAZARD - Small parts. Not suitable for children under 3 years.



**WIRELESS RC ACTION!**



# VENGEOANCE



# VENGEOANCE

RADIO CONTROLLED ALL-TERRAIN RACE CAR



### EXCITING RC DRIVING ACTION!

- Hyper-Speed Racing On Any Terrain
- Oversized Knobby Tires And 4-Wheel Suspension
- Full Function Wireless Remote
- Available In 2 Frequencies For Competitive Racing



## VENGEOANCE

RADIO CONTROLLED ALL-TERRAIN RACE CAR

### BATTERY INSTALLATION

Operation requires one NiCad rechargeable battery pack (included) for car and one 9V battery (included) for radio controller.

- Carefully remove items from package.
- Open the battery compartment on the back of each item.
- Loosen screws on the back of the car to open the battery cover, and connect the battery pack.
- Replace the battery compartment door.
- Slide open the battery compartment door of the controller.
- Insert the one 9V battery following the correct polarity.
- Replace the battery compartment door.

### BASIC CAR OPERATION

- Forward
- Back Up
- Right Turn
- Left Turn

### SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, snow and snow when operating car.
- Do not operate on uneven or slippery surfaces.
- Never operate car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to the car.
- Keep fingers, hair and loose clothing away from the gears and motor while the car is in motion.
- Do not touch the motor or gears when the car is running.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is required for all operation.

### STERNING ALIGNMENT ADJUSTMENT

- Turn the steering knuckle on the left side of the car to the left or right until the car is straight.
- Turn the steering knuckle on the right side of the car to the left or right until the car is straight.

**BATTERY WARNING:**  
• Do not use the battery pack in any other way than intended.  
• Do not use the battery pack in any other way than intended.  
• Do not use the battery pack in any other way than intended.

**RECYCLING INFORMATION:**  
• This product is made from recycled materials.  
• This product is made from recycled materials.

**MADE IN CHINA**