

# HMDX<sup>®</sup> JAUNT

HX-EP550

## USER GUIDE

AND WARRANTY INFORMATION

## HEY THERE!

Thank you for purchasing the **HMDX Jaunt**. Check out the sections below for all the important information about your new earbuds.

### WE'RE HERE TO HELP

You have questions? We have answers.

Contact a Consumer Relations representative by phone or email to help answer any questions. Please be sure to have the model number of your product available. (Hint: It's HX-EP550)

### WE WANT TO KNOW MORE ABOUT YOU

USA: [www.hmdxaudio.com/customer-support/product-registration](http://www.hmdxaudio.com/customer-support/product-registration)

CAN: [www.hmdxaudio.ca/product-registration](http://www.hmdxaudio.ca/product-registration)

#### USA

✉ [cservice@hmdxaudio.com](mailto:cservice@hmdxaudio.com)

☎ 1-800-753-3000  
8:30am–7:00pm EST M–F

#### CANADA


✉ [cservice@homedicsgroup.ca](mailto:cservice@homedicsgroup.ca)

☎ 1-888-225-7378  
8:30am–5:00pm EST M–F

### JUST CHARGE IT

Charging the earbuds is so easy you've probably figured it out by now, but just in case, you have 2 options: You can charge them using your computer or a wall outlet. The Jaunt earbuds need to charge about 2 hours for up to 12 hours of play time.

1. The cord that came with the earbuds – the one with the USB on one end and the micro USB on the other – will work with your computer.
2. If you want to use the wall outlet, you'll need to pick up a power cord with a micro USB the next time you're at the store, or use any USB AC adapter, like the one for your cell phone.



### CONTROL YOUR DESTINY ... OR AT LEAST YOUR EARBUDS



1. Multi-function button (on/off, play/pause)
2. Micro USB charging port
3. LED status light


### SHED SOME LIGHT

What it looks like	What it means
Flashing blue and red	Pairing mode
Slow flashing blue	Connected
Slow flashing red	Low battery
Solid red	Charging
No LED	Fully charged

## BLUETOOTH® CONNECTION – IT'S A SETUP

Like any amazing couple, this one starts with a connection — one between your device and the earbuds' Bluetooth. Here's how it works:

1. Make sure the smartphone, tablet, or computer you're using with the earbuds has Bluetooth.
2. If your earbuds do not automatically turn on after removing them from the charging case, turn on the earbuds by pressing and holding the play/pause button for 2 seconds (look for the little blinking light). The right earbud will blink red and blue alternately and the left earbud will blink blue.
3. Do whatever your device needs you to do on that end to turn on Bluetooth.
4. Look for "Jaunt" in your device's Bluetooth list, or click yes.



## LOOK MA, NO HANDS!

When friends call to interrupt your party of one — and you know they will — answer the phone without disconnecting from your Jaunt earbuds. Yes, that's right. Your earbuds have hands-free calling, too. How amazing is that?

Here's how it works:

1. Make sure your phone and earbuds are connected through Bluetooth.
2. Answering and ending a call work the same way: Just click the play/pause button on your Jaunt.

Check out the chart below for a complete guide on handling calls with your Jaunt earbuds.

Situation	Short press play/pause button	Long press play/pause button
Incoming call	Pick up call	Reject call
On call	End call	Move call from earphones to device
Second incoming call	Answer second call, first call on hold	Reject second call

## COMING CLEAN

A soft, dry towel is all you need to clean off your earbuds. Using water, harsh cleaners, or anything else only messes with the mechanics inside.

## TROUBLESHOOTING

1. Turn off Bluetooth on your device.
2. Take earbuds out of your case.
3. Press and hold "play/pause" button for 5 seconds on both earbuds to turn them off.
4. Press and hold "play/pause" button for 2 seconds on both earbuds to turn them on.
5. Earbuds should automatically go into sync mode once powered on. The master (left) earbud LED will flash blue and red alternately, while the slave (right) earbud LED will slow flash blue. If they do not automatically go into sync mode, quick-press "play/pause" button twice on both earbuds to put into sync mode.
6. Turn on Bluetooth.
7. Pair to "HMDX Jaunt".

5. Now hit play on your earbuds and crank it up — or down if you're lame. The device and the Bluetooth will find each other every time as long as the earbuds are set to Bluetooth and your device's Bluetooth is, you know, on. If you're connecting to a computer, you may have some extra steps on that end. You'll have to get that information from the computer company. Depending on your device, you may be prompted to enter a pairing code. If prompted, enter "0000" as the code. Your earbuds will automatically enter pairing mode. Note: If you turn on your Jaunt earbuds but haven't started the party yet, they will automatically power off after 15 minutes of unpaired inactivity.

## 1-YEAR LIMITED WARRANTY

For detailed warranty instructions and information, visit:  
USA: [www.hmdxaudio.com/customer-support/warranty-1yr](http://www.hmdxaudio.com/customer-support/warranty-1yr)  
CAN: [www.hmdxaudio.ca/warranty-1yr](http://www.hmdxaudio.ca/warranty-1yr)

## STUFF OUR LAWYERS MAKE US SAY

### IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING.

- **WARNING:** Listen responsibly. To avoid hearing damage, make sure the volume on your device is turned down before connecting the earbuds. After placing the earbuds on, gradually turn up the volume until you reach a comfortable listening volume.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to smartphones, iPod/MP3 players, or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOT A TOY.
- Never operate this product if it has a damaged cord, plug, cable, or housing.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

To obtain warranty service on your HMDX product, contact a Consumer Relations representative by telephone or email for assistance (you can find their contact info on page 1). Please make sure to have the model number of the product available.

## A MESSAGE FROM THE ENVIRONMENT

### WARNING:

This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local, state, province, and country guidelines.

This product contains small parts that may present a choking hazard for young children.

**CAUTION:** All servicing of this product must be performed by authorized HMDX Audio service personnel only.

©2019 HMDX. All rights reserved. HMDX is a registered trademark of FKA Distributing Co. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by HMDX is under license.  
IB-HXEP550





©2015–2018 HMDX. All Rights Reserved.  
PP-LCHMDXHPD



**Warranty and Safety Information**  
Información de garantía y seguridad  
Information sur la garantie et de sécurité

FCC ID: TG3-HXEP550  
IC: 20834-HXEP550

#### ENGLISH

##### FCC WARNING:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

##### FCC RF Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

##### ISED CAUTION:

This device complies with Innovation, Science, and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

##### ISED RF Exposure Statement:

The device complies with RF exposure guidelines; users can obtain Canadian information on RF exposure and compliance.

##### 1-YEAR LIMITED WARRANTY

For detailed Warranty instructions and information visit:  
[hmdxaudio.com/customer-support/warranty-1yr](http://hmdxaudio.com/customer-support/warranty-1yr).

To obtain warranty service on your HMDX product, contact a Consumer Relations representative by the telephone number or email address for your country of residence. Please make sure to have the model number of the product available.

##### For service in the USA

email: [cservice@hmdxaudio.com](mailto:cservice@hmdxaudio.com)  
tel: 1-800-753-3000  
8:30am - 7:00pm EST M-F

##### For service in Canada

email: [cservice@homedicsgroup.ca](mailto:cservice@homedicsgroup.ca)  
tel: 1-888-225-7378  
8:30am - 5:00pm EST M-F

##### IMPORTANT SAFETY INSTRUCTIONS:

###### READ ALL INSTRUCTIONS BEFORE USING.

- WARNING: Listen responsibly. To avoid hearing damage, make sure the volume on your device is turned down before connecting headphones. After placing headphones on your ears, gradually turn up the volume until you reach a comfortable listening volume.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to smartphones, iPod/iPad/MP3 players, or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOT A TOY.
- Never operate this product if it has a damaged cord, plug, cable or housing.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

**WARNING:** This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local, state, province, and country guidelines.  
This product contains small parts that may present a choking hazard for young children.

**CAUTION:** All servicing of this product must be performed by authorized HMDX service personnel only.

For complete user guide and to register your product, visit [www.hmdxaudio.com](http://www.hmdxaudio.com) (USA) or [www.hmdxaudio.ca](http://www.hmdxaudio.ca) (Canada)

#### FRANÇAIS

##### AVERTISSEMENT DE LA FCC :

Cet appareil a été testé et jugé conforme aux limites applicables aux appareils de Classe B, conformément à la Partie 15 du règlement de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet appareil génère, utilise et peut émettre une énergie de radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions, peut causer des interférences nuisibles aux communications radio. Il n'est toutefois pas garanti que des interférences ne se produiront pas dans une installation particulière. Si cet appareil provoque des interférences nuisibles à la réception radio ou télévision, ce qui peut être déterminé en éteignant l'appareil et en le rallumant, il est recommandé d'essayer de corriger les interférences en prenant une ou plusieurs des mesures suivantes :

- Réorienter ou déplacer l'antenne de réception;
- Augmenter la distance entre l'appareil et le récepteur;
- Brancher l'appareil dans une prise sur un circuit différent de celui au-quel le récepteur est branché;
- Consulter le revendeur ou un technicien radio/TV expérimenté pour obtenir de l'aide.

Les changements ou modifications non expressément approuvés par l'autorité responsable de la conformité peuvent annuler l'autorisation d'utiliser l'équipement.

Cet appareil est conforme à la partie 15 du règlement de la FCC. Son fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas provoquer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

##### Déclaration de la FCC relative à l'exposition aux RF :

Cet équipement est conforme aux limites d'exposition aux radiations de la FCC établies pour un environnement non contrôlé.

Cet émetteur ne doit pas être localisé ou fonctionner avec une autre antenne ou un autre émetteur.

FCC ID: TG3-HXEP550  
IC: 20834-HXEP550

## MISE EN GARDE D'ISEDC :

Cet appareil est conforme aux normes d'Innovation, Sciences et Développement économique Cana-da pour les appareils radio exempts de licence. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas provoquer d'interférences nuisibles, et
- (2) cet appareil doit accepter toute interférence reçue, y compris celles qui peuvent provoquer un fonctionnement indésirable de l'appareil.

## Déclaration de l'ISEDC relative à l'exposition aux RF :

L'appareil est conforme aux directives d'exposition RF. Les utilisateurs peuvent obtenir de l'information canadienne sur l'exposition aux RF et la conformité.

## GARANTIE LIMITÉE D'UN AN

Pour de plus amples renseignements et instructions au sujet de la garantie, veuillez visiter le site : <http://www.hmdxaudio.com/customer-support/warranty-1yr>

Pour obtenir un service couvert par la garantie pour votre produit HMDX, contacter un représentant de notre service à la clientèle par téléphone ou par courriel aux coordonnées pour votre pays de résidence. N'oubliez pas d'avoir en main le numéro de modèle de votre produit avant de contacter notre service à la clientèle.

### Pour les services aux États-Unis

courriel : [cservice@hmdxaudio.com](mailto:cservice@hmdxaudio.com)

tél : 1-800-753-3000

Du lundi au vendredi, de 8 h 30 à 19 h (HE)

### Pour les services au Canada

courriel : [cservice@homedicsgroup.ca](mailto:cservice@homedicsgroup.ca)

tél : 1-888-225-7378

Du lundi au vendredi, de 8 h 30 à 17 h (HE)

## CONSIGNES IMPORTANTES DE SÉCURITÉ

### LISEZ TOUTES LES DIRECTIVES AVANT D'UTILISER L'APPAREIL.

- **AVERTISSEMENT** : écoutez votre musique de manière responsable. Pour éviter tout risque de diminution de l'acuité auditive, assurez-vous de baisser le volume de votre appareil avant de brancher vos écouteurs. Placez les écouteurs sur les oreilles et ensuite augmentez graduellement le volume jusqu'au niveau souhaité.
- Utilisez cet appareil uniquement pour les fonctions qui lui sont attribuées, conformément au présent manuel. N'utilisez pas d'accessoires non recommandés par HMDX.
- HMDX n'est pas responsable des éventuels dommages causés à un téléphone intelligent, à un lecteur MP3, un iPod ou tout autre appareil.
- N'installez ou ne rangez pas l'appareil dans un endroit où il peut tomber ou être tiré dans une baignoire ou un lavabo.
- Ne placez pas ou ne faites pas tomber l'appareil dans de l'eau ou d'autres liquides.
- Cet appareil n'est pas conçu pour les enfants. CECI N'EST PAS UN JOUET.
- Ne faites jamais fonctionner l'appareil si un fil, une prise, un câble ou le boîtier est endommagé.
- Maintenez l'appareil loin des surfaces chaudes.
- Installez l'appareil uniquement sur une surface sèche. Ne placez pas l'appareil sur une surface mouillée par de l'eau ou un solvant.

**AVERTISSEMENT** : ce produit possède une pile au lithium intégrée non remplaçable.

Veuillez jeter le produit conformément aux lignes directrices locales, étatiques, provinciales, territoriales et nationales.

Cet appareil contient des petites pièces pouvant présenter un risque d'étouffement pour de jeunes enfants.

**MISE EN GARDE** : Toute réparation de cet appareil doit uniquement être effectuée par le personnel de service autorisé HMDX.

**Pour consulter un guide complet de l'utilisateur et enregistrer votre appareil, visitez [www.hmdxaudio.com](http://www.hmdxaudio.com) (É.-U.) ou [www.hmdxaudio.ca](http://www.hmdxaudio.ca) (Canada)**

## ESPAÑOL

### ADVERTENCIA DE FCC:

Este equipo ha sido probado y se encontró que cumple con los límites de un dispositivo digital Clase B, de conformidad con la parte 15 de las Reglas de FCC. Estos límites están diseñados para proporcionar una protección razonable contra la interferencia dañina en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia y si no se instala y usa de conformidad con las instrucciones, puede ocasionar interferencia dañina a las radiocomunicaciones. Sin embargo, no hay garantías de que no ocurra interferencia en una instalación en particular. Si este equipo causa interferencia dañina en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se sugiere al usuario que trate de corregir la interferencia tomando una o más de las siguientes medidas:

—Reorienta o reubica la antena receptora.

—Aumente la separación entre el equipo y el receptor.

—Conecte el equipo a un enchufe de un circuito diferente al que esté conectado el receptor.

—Consulte al distribuidor o a un técnico experimentado de radio y TV para obtener ayuda.

Cualesquiera cambios o modificaciones no aprobados expresamente por la parte responsable del cumplimiento podrían anular la capacidad del usuario para operar el equipo.

Este dispositivo cumple con la parte 15 de las reglas de la FCC. El funcionamiento está sujeto a las siguientes dos condiciones: (1) Este dispositivo no puede causar interferencia perjudicial, y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluyendo aquellas interferencias que puedan provocar un funcionamiento no deseado.

### Declaración de exposición a RF de FCC:

Este equipo cumple con los límites de exposición a la radiación de la FCC establecidos para un ambiente no controlado.

Este transmisor no debe colocarse en forma conjunta ni operarse junto con cualquier otro transmisor o antena.

### GARANTÍA LIMITADA POR UN AÑO

Para instrucciones detalladas de su Garantía e información visite:

<http://www.hmdxaudio.com/customer-support/warranty-1yr>

Para obtener servicio de garantía en su producto HMDX, contacte al representante de relaciones de usuarios usando el teléfono o dirección de email en su país de residencia. Por favor asegúrese de tener a mano el número de modelo de su producto.

### Para servicio en los EEUU

email: [cservice@hmdxaudio.com](mailto:cservice@hmdxaudio.com)

tél : 1-800-753-3000

8:30am - 7:00pm EST L-V

### Para servicio en el Canada

email: [cservice@homedicsgroup.ca](mailto:cservice@homedicsgroup.ca)

tél : 1-888-225-7378

8:30am - 5:00pm EST L-V

## INSTRUCCIONES DE SEGURIDAD IMPORTANTES

### LEA TODAS LAS INSTRUCCIONES ANTES DE USAR

- **ADVERTENCIA:** Escuche con responsabilidad. Para evitar daños a la audición, asegúrese de que el volumen de su dispositivo esté al mínimo antes de conectar los auriculares u audífonos. Después de colocar los auriculares u audífonos en sus oídos, gire gradualmente el volumen hasta llegar a un volumen confortable.
- Utilice este producto sólo para el uso que se describe en este manual. No utilice accesorios que no hallan sido recomendados por HMDX.
- HMDX no se hace responsable de los daños causados a los smartphones, iPod / reproductor de MP3 o cualquier otro dispositivo.
- No coloque ni guarde este producto donde pueda caerse o ser tirado en una tina o un lavabo.
- No coloque ni deje caer en agua o cualquier otro líquido.
- No para uso de los niños. ESTO NO ES UN JUGUETE.
- Nunca utilice este producto si tiene dañando el cable, el enchufe, o el armazón.
- Mantener alejado de superficies calientes.
- Sólo coloque este dispositivo en superficies secas. No lo coloque sobre superficies mojadas con agua o solventes de limpieza.

**ADVERTENCIA:** Este producto tiene una batería interna de litio, que no está diseñada a ser reemplazable. Por favor, deseche de acuerdo con las regulaciones locales, estatales, provinciales o requisitos nacionales. Este producto contiene piezas pequeñas que pueden presentar un peligro de asfixia para los niños pequeños.

**PRECAUCIÓN:** Todo el servicio de este producto debe ser realizado solamente por el personal de servicio autorizado por HMDX.

**Para la guía de usuario completa y para registrar su producto, visite [www.hmdxaudio.com](http://www.hmdxaudio.com) (EEUU) o [www.hmdxaudio.ca](http://www.hmdxaudio.ca) (Canada)**