

MIX

USER GUIDE AND WARRANTY INFORMATION

HEY THERE!

Thank you for purchasing the **HMDX Dynamite**. Check out the sections below for all the important information about your new speaker.

WE'RE HERE TO HELP. CONTACT US!

You've got questions? We've got answers.

Contact a Customer Relations representative by phone, or email to help answer any questions. Please be sure to have the model number of your product available. (Hint: It's HX-HP210)

www.hmdxaudio.com/customer-support/product-registration

<http://www.hmdxaudio.ca/hmdx-support-ca>

USA

✉ cservice@hmdxaudio.com

☎ 1.800.573.3000
8:30am-7:00pm EST M-F

CANADA


✉ cservice@homedicsgroup.ca

☎ 1.888.225.7378
8:30am-5:00pm EST M-F

JUST CHARGE IT

Charging the headphones is so easy you've probably figured it out by now, but just in case, you've got two options: you can charge it using your computer or a wall outlet. The Mix headphones need about 2 hours for up to 8 hours of play time.

1. The cord that came with the – the one with the USB on one end and the Micro USB on the other – will work with your computer.
2. If you want to use the wall outlet, you'll need to pick up a power cord with a Micro USB the next time you're at the store, or use any USB AC adapter, including the one for your cell.



AC adaptor not included

CONTROL YOUR DESTINY... OR AT LEAST YOUR SPEAKER



1. Press for volume up/hold for 2s to skip track.
2. Multifunction Button (see Bluetooth section to turn on/connect)
3. Turn the Music down. (Press and hold for 2s to move to the previous track).
4. Microphone
5. Micro USB charging port

SHED SOME LIGHT

What it looks like	What it Means
Flashing Blue and Red	Pairing Mode
Slow Flashing Blue	Connected
Slow Flashing Red	Low Battery
Red	Charging
No LED	Fully charged

BLUETOOTH® CONNECTION – IT'S A SETUP

Like any amazing couple this one starts with a connection – one between your device and the headphone's *Bluetooth*. Here's how it works:

1. Make sure the smartphone, tablet or computer you're using with the headphones has *Bluetooth*.
2. Turn on the headphones by pressing and holding MULTIFUNCTION button for 2 seconds and look for the little blinking light on the back of the control box.
3. Do whatever your device needs you to do on its end to turn on *Bluetooth*.
4. Look for Mix in your device's *Bluetooth* list or click YES.
5. Now hit PLAY on your earbuds and crank it up - or down if you're lame.

The device and the *Bluetooth* will find each other every time just as long as the headphone's are set to *Bluetooth* and your device's *Bluetooth* is, you know, on.

If you're connecting to a computer, you may have some extra steps on that end. You'll have to get that information from the computer company.



Depending on your device you may be prompted to enter a pairing code. If prompted, enter "0000" as the code.

Your headphones will automatically enter pairing mode.

Note: If you turn on your Mix headphones but haven't started the party yet, it will automatically power off after 2 minutes of unpaired inactivity.



LOOK MA, NO HANDS!

When friends call asking to join the party – and you know they will – answer the phone without disconnecting from your Mix headphones. Yes, that's right. Your headphones have hands-free calling too. How amazing is that? Here's how it works:

1. Make sure your phone and headphones are connected through *Bluetooth*.
2. Answering and ending a call works the same way: simply click the MULTIFUNCTION button on your mix.

3. If you'd rather not talk, hold down the MULTIFUNCTION button on your headphones for 2 seconds to ignore the call.

THE COOLEST PART: The Mix headphones know when a call is coming in and pauses the music before ringing. When you hang up, the music starts where it left off – and so does the party. If it's you making the call, just start dialing from your phone, and the Mix automatically does its hands-free calling thing. Isn't it refreshing to know your speaker totally gets you?

Situation	Short Press Play/Pause Button	Long Press Play/Pause Button
1 st Incoming call	Pick up call	Reject call
On call	End call	Move call from headphones to device

COMING CLEAN

A soft dry towel is all you need to clean off your headphones. Using water, harsh cleaners, or anything else only starts messing with the mechanics inside.

1 YEAR LIMITED WARRANTY

For detailed warranty instructions and information visit:

USA: www.hmdxaudio.com/customer-support/warranty-1yr

CAN: www.hmdxaudio.ca/warranty-1yr

To obtain warranty service on your HMDX product, contact a Consumer Relations representative by telephone or email for assistance (you can find their contact info on page 1). Please make sure to have the model number of the product available.

FCC CAUTION:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Compliance statement:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This device is compliance with RF exposure guidelines, user can obtain Canadian information on RF exposure and compliance.

L'appareil est conforme aux directives d'exposition RF, les utilisateurs peuvent obtenir de l'information canadienne sur l'exposition aux RF et la conformité.

STUFF OUR LAWYERS MAKE US SAY

IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

- **WARNING:** Listen responsibly. To avoid hearing damage, make sure the volume on your device is turned down before connecting earbuds. After placing earbuds in your ears, gradually turn up the volume until you reach a comfortable listening volume.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to smartphones, iPod/MP3 players, or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOT A TOY.
- Never operate this product if it has a damaged cord, plug, cable, or housing.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

Attention California Residents:

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects, and other reproductive harm.

A MESSAGE FROM THE ENVIRONMENT

WARNING:

This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local, state, province, and country guidelines.

This product contains small parts that may present a choking hazard for young children.

CAUTION: All servicing of this product must be performed by authorized HMDX Audio Service Personnel only.

©2018 HMDX. All Rights Reserved.
IB-HXHP210

