

TPMS trigger

Model no.: OEC-T5

User manual

Ensure that the vehicle is in the TPMS learn mode, and follow the service procedure.

- 1. Hold tool against the sidewall of the tire, near the valve stem.**
- 2. Depress learn button while holding the tool against the sidewall.**
- 3. The green LED indicates that the tool is transmitting.**

Orange Electronic Co., Ltd