



**Annex C Internal photographs**




172414\_q.jpg: EasyScan USB, internal view 1 (housing opened)

**Annex C Internal photographs**




172414\_r.jpg: EasyScan USB, internal view 2 (housing disassembled)

**Annex C Internal photographs**




172414\_k.jpg: EasyScan USB, internal view 4 (antenna fixing inside housing top cover)

**Annex C Internal photographs**




172414\_j.jpg: EasyScan USB, PCB, antennas inside antenna fixing (housing top cover removed)

**Annex C Internal photographs**




172414\_i.jpg: EasyScan USB, internal view 3 (antenna fixing removed)

**Annex C Internal photographs**




172414\_n.jpg: EasyScan USB, PCB, 125 kHz antenna

**Annex C Internal photographs**



172414\_p.jpg: EasyScan USB, 13.56 MHz antenna, top view


**Annex C Internal photographs**



172414\_o.jpg: EasyScan USB, 13.56 MHz antenna, bottom view




**Annex C Internal photographs**



172414\_I.jpg: EasyScan USB, PCB, top view

**Annex C Internal photographs**



172414\_m.jpg: EasyScan USB, PCB, bottom view