

# Dual Multimedia Headrest Replacement Entertainment System

## Quick Start Guide

## NOTICES

### NOTICE OF INTENDED USE

Rosen Electronics are designed to enable viewing of video ONLY for rear-seat occupants, and are not intended for viewing by the driver when the vehicle is in motion. Such use might distract the driver or interfere with the driver's safe operation of the vehicle, and thus result in serious injury or death. Such use might also violate state or local laws.

Rosen Electronics disclaims any liability for any bodily injury or property damage that might result from any improper or unintended use.

### About the Registered Marks

*This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.*

*NOTE: Features and specifications listed in this manual are subject to change without notice*

*Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.*

iPod® and iPhone® are registered trademarks of Apple, Inc.

---

**For complete Owner's Manual, please visit  
Rosen Electronics online at  
[www.RosenElectronics.com](http://www.RosenElectronics.com)**

---


## Turning On The System

A) Turn vehicle ignition to ON or ACC

B) Press POWER on the front display or wireless remote on each system



## Front Panel Controls




## Using The Headphones

- A) Turn on by pressing the OFF/ON button located on the ear piece. The power LED on the ear piece should illuminate. If not, check that the batteries are inserted properly and have a charge.
- B) The headphones each have a two-position slide switch labeled "Ch.A/Ch.B". They must have a clear line of sight to the headrest monitor and must be switched to the designated A/B Channel to operate properly.
- C) To adjust the volume, use the knob on the ear piece.



## Remote Control



## Playing A Disc

- A) Use the LEFT or RIGHT button to navigate to DVD mode.
- B) Press the ENTER button to select DVD source.
- C) With the label facing away, insert a disc into the disc slot. Do not force disc into slot. If a DVD/CD menu appears on the screen, press PLAY or ENTER as instructed on the screen. Most disc will load and play automatically.
- D) To obtain best viewing angle, adjust the screen display as needed by pressing the bottom corners of the screen housing.



*Note: Not all discs are supported by this system. You may find a disc that will not play on this system, but works fine on other players. Various manufacturers of discs change technology from time to time which may create compatibility issues. This is not a problem with the unit and is not covered by warranty.*

*Please check with the Owner's Manual for more detailed information.*

## Changing The Video Source

- A) Press the HOME button on the front panel of the remote controller.
- B) Use the LEFT or RIGHT button and navigate to the source desired.
- C) Press ENTER to select the source.

*Note: Some of the sources can be accessed directly through the remote controller.*

## Digital Media Player

The USB/MicroSD sources can be used for media playback, such as video, audio and photos.

  Use the LEFT or RIGHT arrows to the next page.

  Use the UP or DOWN arrows to navigate the folder.

  PLAY/PAUSE or ENTER to start playing file.

 RETURN to go back previous screen.

 Use The HOME to return to the main menu.

## External Sources

**HDMI:** The system supports up to 2 external HDMI devices, such as Smart Phone,Tablet, Gaming Console or any device with HDMI output.

**AUX:** A composite 3.5mm AV input at the AV box.

**AV IN:** A composite 3.5mm AV input on the TFT screen.

## Listening Over the Vehicle Speakers

A) Press SPEAKER button on the front control panel.

“SPEAKER SOUND ON FM\_\_ PRESS LEFT OR RIGHT TO  
ADJUST” will appear on the screen.

B) Turn the vehicle's radio on and tune to the FM frequency displayed on the screen.

C) If radio interference is heard, try another frequency.



## Adjusting The Display

From the Home page, navigate to Settings and press Enter.



Press the UP arrow button to brighten the screen or press the DOWN arrow button to dim the screen. Once you are done, press the BACK or HOME button to exit the SETTINGS.

### Auto On Displays

The system can be set to turn on automatically whenever the ACC is on. To set the system to turn on automatically, within the SETTINGS menu press the LEFT arrow button to select Auto On Display. Press either the UP or DOWN arrow button to change settings.

# FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, thereis no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1) Reorient or relocate the receiving antenna.
- 2)Increase the separation between the equipment and receiver.
- 3)Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4)Consult the dealer or an experienced radio/TV technician for help.

PN: QSG1002 Rev A

Copyright © 2015 Rosen Electronics, All rights reserved.