

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Bluetooth Receiver

M35


User Manual | Bedienungsanleitung | Le mode d'emploi

Istruzioni | Manual de usuario | 取扱説明書

English	01
Deutsch	09
Français	17
Italiano	25
Español	33
日本語	41

En

Structure Diagram



Specifications

Bluetooth Version: V4.1

Bluetooth Mode: A2DP, HFP, HSP, AVRCP

Bluetooth Range: Up to 10m

Dimension: 30x30x15mm

Music Time: 7.5H

Talk Time: 9H

Standby Time: 270H

Charging Time: ≤2H

Battery: 3.7V 140MAH

Charging the receiver

1. Connect the USB charging cable to the USB charge port of the receiver.
2. The light indicator will turn into orange when charging.
3. The full charge take about 2 hours.
4. The white light indicator goes on when charging completed.

5. **Low-Battery Alert:** When the battery is lower than 3.4V, orange light instead of white light starts work, the voice prompt is "Battery Low" every minute.

Tips:

1. Before using the receiver, please read the manual carefully and keep it for future references.
2. The receiver needs to be fully charged prior to first-time use.
3. If the receiver is left unused for over two weeks, please recharge it periodically.
4. Use only chargers made by qualified manufacturer.

Power on/off the receiver

Power on:

With the earphone off, press and hold "MFB" for about 3 second until the white light on, you will also hear a voice "power on"

Power off:

In the state of power-on, press and hold the "MFB" for 4 seconds until the indicator blinks orange, you will also hear a voice "power off"

Pair to your phone

1. Long press and hold the MFB button for 4 seconds until the orange and white light start flashing alternately, the voice prompt is "paring" and it will automatically enter the pairing mode.
2. Turn on the Bluetooth function of your phone or other devices, search the Bluetooth devices and select "M35" to connect.
3. Enter the code "0000" if needed.
4. Once paired successfully, the voice prompt is "Connected", then the indicator light turns into white and starts flash every 7 seconds.

Remarks: It will connect to the last paired smart device automatically when it's turned on next time. Please make sure the Bluetooth function of your smart device is turned on before turn on the headset.

Connect two Bluetooth devices at the same time

1. Pair the Bluetooth receiver to the first phone.

2. After pair successfully, long press and hold the MFB button for 4 seconds until the orange and white light start flashing alternately.
3. Pair the Bluetooth receiver to the second phone, repeat the first connection step.
4. After pair successfully, make sure Bluetooth is active on your mobile phone on the menu of the first phone.
5. Paired successfully.

Clear the Pairing Memory

Long press and hold Volume + and "MFB" for 4 seconds, the indicator light turns into orange for 2 seconds in standby.

Entering into DFU Mode

Long press and hold the function button, Volume - for 4 seconds and insert the USB in standby.

Answering / Hanging up a call

Answering: Short press MFB button when there is an incoming call.

Hanging up: Short press MFB button when on a call.

Rejecting a call

Long press and hold MFB buttons until hear the voice prompt when there is an incoming call.

Last Number Redial

Double-click MFB button in standby / music, the voice prompt is "Last Number Redial".

Three-way Calling

1. If you are already on the call while there is another incoming call, long press MFB button for 2 seconds to reject the incoming call.
2. If you are already on the call while there is another incoming call, double-click MFB button , hold the current call and answer the incoming call.
3. If you are already on the call while there is another incoming call, short press MFB button, hang up the current call and answer the incoming call.

4. If the phone is already on the call while another phone is hold on, double-click MFB button , hold the current call and answer the hold-on calling.

5. If you are already on the call while another phone is hold on, short hold MFB buttons, hang up the current call and answer the hold-on calling.

Mute Function

Press Volume + and Volume - simultaneously when already on the call, a mute reminder beep will be heard every 10 seconds.

Voice Dialing

Voice Dialing: Long press MFB button for 1 second then release in standby/music mode, the voice prompt is "Voice Dial".

Ending voice dialing: Long press MFB button for 1 second in voice dialing and then release.

Playing Music

Play/Pause: Press MFB button in standby / music.

Previous Song: Long press the button ►► for 2 seconds when playing music.

Next Song: Long press the button ◀◀ for 2 seconds when playing music.

Volume up: Short press the button + when answering a call or playing music.

Volume down: Short press the button - when answering a call or playing music .

Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.