FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### 15.21 Information to user.

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to

try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

For portable devices

FCC RF Radiation Exposure Statement:

- 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- 2. This equipment complies with FCC RF radiation

exposure limits set forth for an

uncontrolled environment. This device was tested for typical hand held operations with the device contacted

directly to the human body to the sides of the device. To maintain compliance with FCC RF exposure

compliance requirements, avoid direct contact to the transmitting antenna during transmitting.

# BS036RD

# Bluetooth Stereo Headset User Manual

Bluetooth headset should be used with the compatible devices which support bluetooth wireless technology. This allows you the freedom to make any calls and enjoy the music streaming at any time.

Please read this user manual carefully before using the headset, and also read your device's user manual regarding the bluetooth function, and pay attention to those important safety and maintenance information.

Please keep the headset away from children.

# **Specifications**

Bluetooth Specification V3.0

Bluetooth Profiles Supported Headset, Handsfree, A2DP, AVRCP

Transmission Power Class 2
Operation Range Up to 10 Meters

Frequency Range 2.402~2.480 GHz

Battery Built-in Rechargeable

3.7V /70mAH Li-polymer Battery

5-Charging Socket

6-Microphone

7-Earpiece

Charging Voltage DC4. 75-5. 25V
Charging Time About 2 hours

 Music Playing Time\*
 Up to 3.5 hours

 Talk Time\*
 Up to 4 hours


 Standby Time\*
 Up to 100 hours

 Dimensions(mm)
 L 36 x W14.5 x H6

Weight About 14 g

\*The time mentioned as above may vary due to user's operation mode and device settings.

# **Structure Sketch**



- 1-Volume Key+(V+)
- 2-Speaker
- 3-Volume Key-(V-)
- 4-Multifunction Button(MFB)

# **Basic Operations**

## **Charging Your Headset**

- Prior to using the headset for the first time, please fully charge the battery.
- Approximately 2 hours are required to fully charge the headset.
- The indicator light turns red while being charged, and will turn to blue automatically after being fully charged.
- When the headset is running out of battery, the indicator light will flash red(the headset will switch off automatically when the battery is drained). Please charge the headset as above steps in time to prolong the battery's using life(Charging indication will be delayed for a few minutes if the headset has not been used for a long time or the battery is drained).

#### Note:

- Use only the supplied charger to charge the headset, or could be dangerous and obey the validation for this product or the maintenance article.
- Do not attempt to force open the built-in battery as this could damage the headset.
- If left unused, a fully charged headset will loose its power automatically. It is recommended to charge the headset each three months.
- Do not leave the headset in a too hot or too cold condition (best between 15<sup>™</sup>C and 25<sup>™</sup>C) which may affect the headset's operations although it is fully charged.
- Do not dispose of the headset into a fire or water.

## Turning on the Headset

In OFF MODE, press and hold MFB for 2 seconds until you hear a short beep and the indicator light flashes blue for 3 times, then the headset will enter into STANDBY MODE.

## Turning off the Headset

In ON MODE, press and hold MFB for 5 seconds until you hear a short beep and the indicator light flashes red for 3 times, then the headset will enter into OFF MODE.

# Pairing Your Headset with a Bluetooth Mobile Phone

- Ensure the headset is off, and the distance between your headset and phone is within 1 meter.
- 2.Press and hold MFB until you hear a beep and the indicator light flashes red and blue alternately as PAIRING MODE.

- 3.Activate the bluetooth function on the phone, and search bluetooth devices (See the user quide of your phone for instructions).
- 4. Select headset "BS036RD" from the found devices list of the phone.
- 5.Enter the passkey "0000", confirm to pair the headset with your phone and headset will enter into connecting mode. (If the pairing cannot be completed within 5 minutes after the PAIRING MODE has been activated, the headset will enter into the STANDBY MODE. Repeat above steps to do the pairing again).
- 6.Ensure the distance between your headset and phone is within 10 meters, and without any obstacles, you can use the headset freely.
- 7.If the headset has paired with your phone but disconnected, it will connect the paired phone automatically when you turn on the headset again within operation range.

#### **Answering a Call**

Press MFB once.

#### Ending a Call

Press MFB once.

## Rejecting a Call

Press and hold MFB for 2 seconds.

## **Voice Dialing**

In STANDBY MODE, press MFB for about 2 seconds and say the voice tag as soon as you hear the short beep(ensure your phone supports voice dialing function, and you have recorded the voice tag into your phone. See the user guide of your phone for instructions)

## Last Number Redialing

Press MFB twice.

## **Adjusting Volume**

Press V+ or V- shortly to adjust the volume

## **Power Saving**

The headset will turn off automatically if it can not be paired or connected with any devices within 20 minutes.

# Audio Remote-control Function Play/Pause

Press MFB once for music playing, and press again to pause.

#### Forward

Press and hold V- button to forward to the next song

#### Backward

Press and hold V+ button to backward to the last song.

**Note:** Ensure your paired devices support AVRCP Bluetooth Profile to realize remote-control use.

#### Disconnecting

To disconnect the paired headset from your phone, please turn off the headset or disconnect the headset from the Bluetooth menu of your phone.

#### **Care and Maintenance**

- Do not use abrasive cleaning solvents to clean the headset.
- Do not allow the headset to touch with any sharp objects since this will cause scratching and damage.
- Be sure to store the headset in a dry place, free from extreme high temperatures, humidity and dust.