

## Label information

RKE-4F47

MODEL: RKE-4F47

FCC ID: TQ8-RKE-4F47

IC: 5074A-RKE4F47

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.