




# **Annex A**


## **Spurious Emissions**



1-18 GHz High Channel




1-18 GHz Low Channel






1-18 GHz Mid Channel




18-26.5 GHz High Channel






18-26.5 GHz Low Channel




18-26.5 GHz Mid Channel






### 26.5-40 GHz High Channel




### 26.5-40 GHz Low Channel






### 26.5-40 GHz Mid Channel




### 30 MHz-1GHz High Channel






### 30 MHz-1GHz Low Channel




### 30 MHz-1GHz Mid Channel






### 33-50 GHz High Channel




### 33-50 GHz Low Channel








33-50 GHz Mid Channel




50-75 GHz high Channel






50-75 GHz low Channel




50-75 GHz mid Channel






75-110 GHz high Channel



75-110 GHz low Channel





75-110 GHz Mid Channel

