

1. Photographs of Conducted Emissions Test Configuration - USB mode

Front view



Side view



Under table view



2. Photographs of Conducted Emissions Test Configuration - Adapter mode


Front view



Side view




Under table view




3. Photographs of Radiated Emissions Test Configuration - USB mode

For radiated emissions 30MHz~1GHz

Front view




Rear view



For radiated emissions above 1GHz

Front view




Rear view




4. Photographs of Radiated Emissions Test Configuration - Adapter mode

For radiated emissions 30MHz~1GHz

Front view



Rear view



————THE END————