



QUICK START GUIDE


I. TURN ON YOUR NEW BEOPLAY HX




II. DOWNLOAD THE BANG & OLUFSEN APP



III. ENJOY MUSIC




BANG & OLUFSEN APP



Product settings Beosonic


CONTENTS




BANG & OLUFSEN

QUICK START GUIDE


GESTURES



Tap
Play/Pause



Swipe
Next/Previous



Swipe
Volume (Up/Down)

