

US UK

Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

1

OS support

Windows 8/10
Tablet with Bluetooth V4.0 or above.
Smart phone with Bluetooth V4.0 or above.

Keyboard layout and button instruction

- A. Power Switch ON/OFF**
- B. Bluetooth channel Dragonworrior 1/ Dragonworrior 2/ Dragonworrior 3**
- C. Bluetooth(charging) indicator**

The bluetooth indicator locates between [ESC] and [F1] key, the indicator flashes in blue while in pairing with another device. It goes off when pairing finished.

D. Battery indicator

1. Low power indicator: [M]key will be twinkle when keyboard in low power.
2. Charging indicator: Bluetooth(charging) indicator will light on in red while charging, and turn to green when charging finished.

Wired Connection

1. Slide the ON/OFF switch on bottom of the keyboard to OFF.
2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer.
3. The computer will recognize and configure the keyboard automatically.
4. The keyboard will be ready for use when the configuration is finished.
5. Once the keyboard is powered up, charging begins. The LED marked with M light s on red. It will turn to green when keyboard is fully recharged

Warning: Charging Input: 5V ---1A

2

Bluetooth Connection

1. Slide the ON/OFF switch on bottom of keyboard to ON.
2. Press [FN]+[Q](or [W]/[E] for other Bluetooth devices)for about five seconds, the Bluetooth(Charging)LED flashes quickly in blue.
3. Turn on Bluetooth and scan for available devices on your computer ,laptop, tablet or smart phone. It will find "Draconic-1 "(or Draconic-2 or Draconic-3)device. Select one of them to get connected.
4. The Bluetooth(Charging) LED goes off when pairing finished.

How to recharge keyboard

Find the USB A to USB type C cable in the packaging ,plug the keyboard and connect it with computer for charging, the Bluetooth(Charging) LED indicator of keyboard will twinkle in red while charging. It turns to green and stops twinkling when charging finished. It may take about 3 hours to be fully recharged.
Remark: The LED indicator (M) will turn to red when keyboard is out of battery.

Key Function Introduction

Keyboard backlighting adjustment

1. [Fn] +[M]Switch keyboard backlight within 18 lighting effects.
2. [Fn] +[↑]:Increase the backlight brightness of the keyboard, total 5 levels.
3. [Fn] +[↓]: Decrease the backlight brightness of the keyboard, total 5 levels.
4. [Fn] +[-]: Slow down light running speed ,total 5 levels.
5. [Fn] +[+]: Speed up light running speed ,total 5 levels..
6. [Fn] +Spacebar: Set backlight color with the color palette. Press [Fn]+Spacebar to light up color palette shown with the whole keyboard, select one of the key with which the color it shows, the whole keyboard will light on in this color then. Repeat to select another colorfor the keyboard.

3

7. [Fn]+[-~]: Select or set customized backlight. Press [Fn]+[-~] to select customized backlight. Press [Fn]+[-~] twice to set the backlight for each key.The [CapsLK],[Win] and [Num] key will flash in red together. Press FN+[] to change the wanted color which shows the same as [-~] itself. Type any key to be lit up in that color or press FN+[→] repeatedly to another color. Press FN+[] once again to save the settings.

Keyboard side lighting adjustment

1. [Fn] +[Alt_L] Switch keyboard side light within 12 lighting effects.
2. [Fn] +[X]Adjust side light brightness.
3. [Fn] +[Z]Adjust side light running speed.

Other functional key combinations:

[Fn] +[ESC]:Back to factory setting
[Fn] +[WIN]: Lock /Unlock Windows Key
[Fn] +[]=Insert
[Fn] +[]=Delete
[Fn] +[;]=Home
[Fn] +['] =End
[Fn] +[>]=PgUp
[Fn] +[/?]=PgDn

4

Multi-media keys (FN+F1~F12)

| | | |
|------------|--|----------------|
| [FN]+[F1] | | Media player |
| [FN]+[F2] | | Volume Down |
| [FN]+[F3] | | Volume Up |
| [FN]+[F4] | | Mute |
| [FN]+[F5] | | Stop |
| [FN]+[F6] | | Previous Track |
| [FN]+[F7] | | Play/Pause |
| [FN]+[F8] | | Next Track |
| [FN]+[F9] | | E-mail |
| [FN]+[F10] | | Home |
| [FN]+[F11] | | Calculator |
| [FN]+[F12] | | Search |

5

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.



6

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

California Proposition 65

WARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure - www.P65Warnings.ca.gov

7



REDRAGON

DRAGONWARRIOR

MECHANICAL GAMING KEYBOARD



Please scan here to download user manual

Mechanical Gaming Keyboard Operating Instructions

| | | |
|----|------------------|------------------------|
| 型号 | 红龙K603P-KBS/8516 | 备注：尺寸：100x100mm (风琴折页) |
| 名称 | 说明书 | 材质：80g书写纸 |
| 日期 | 2022-2-26(修改) | 印刷：单黑色双面印刷 |
| 页码 | 1 OF 1 | 文件编号 |
| 绘图 | 雷国建 | 审核 |
| | | 核准 |
| | | 版本 |
| | | A.0 |