

Dear user

Thank you for choosing **REDRAGON** product. To protect your rights and for better customer service, please read the following warranty rules carefully.

- 1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
- 2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

OS support

Windows XP/ Vista/ Win 7/ Win 8/ Win 10/Mac OS

How to connect the keyboard with a computer **Wired Connection**

- 1. Slide the 2.4G/OFF/BT switch on bottom of the keyboard to "OFF".
- 2. Take out the USB A to USB Type C cable in the package and connect the keyboard with
- 3. The computer will recognize and configure the keyboard automatically.
- 4. The keyboard will be ready for use when the configuration is finished
- 5. Once the keyboard is powered up, charging begins. The LED marked with "M" on the left side of the keyboard will flash in white and then lights on red. It will turn to white when keyboard is fully recharged.

2.4G Wireless Connection

- 1. Slide the 2.4G/OFF/BT switch on bottom of keyboard to "2.4G".
- 2. Take out the nano USB receiver and plug it into an available USB port on your computer. The computer will recognize and configure the keyboard automatically.
- 3. The keyboard will be ready for use when the configuration is finished.
- 4. In some cases, you may need to pair the keyboard. Turn on the keyboard and press [FN]+[R] for about 3 seconds, the LED marked with "M" flashes quickly in green, plug the USB receiver into any available USB port on your computer within 20 seconds. The keyboard will be paired automatically. Make sure the keyboard has enough power before doing so.
- 5. The indicator will flash when the battery is low. Please recharge the keyboard in time or it will turn off automatically soon.

Bluetooth Connection

- 1. Slide the 2.4G/OFF/BT switch on bottom of keyboard to "BT".
- 2. Press [FN]+[Q](or [W]/[E] for other Bluetooth devices), the LED marked with "M" flashes in blue (or cyan/magenta for the others)
- 3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0Keyboard" or "BT5.0 KB" device. Select one of them to get connected

with it automatically.

Function Introduction

- 1. With standard USB and 2.4G/BT connections, the keyboard can be used on computers without any software or driver installation.
- 2. There are 20 backlight effects.
- 3. Commands of key combinations with [FN] key

[FN]+[TAB]: Turn the backlight to white.

[FN] + [Win]: Disable or enable the [Win] key.

[FN] + [Q]: Select Bluetooth device one (for Bluetooth connection).

[FN] + [W]: Select Bluetooth device two (for Bluetooth connection). [FN] + [E]: Select Bluetooth device three (for Bluetooth connection).

[FN] + [R]: Change to 2.4G wireless connection. Press and hold the

[FN]+[R] for 3 seconds to pair the keyboard with the receiver.

[FN] + [P]: Print Screen

[FN] + [[]:Home

[FN] + []]:End

[FN] + [;]:Page Up [FN] + [']:Page Down

[FN] + [.]: Insert

[FN] + [/]: Delete

[FN] + [Esc]: `

 $[\mathsf{FN}] + [\mathsf{Shift}] + [\mathsf{Esc}] : \sim$ [FN] + [1](~[0]): F1(~F10)

[FN] + [=]: F12

4. Commands of key combinations with [fn] key

[fn]+[8]: Change backlight mode. There are 20 backlight effects.

[fn]+[9]: Change back light color.

[fn] + [0]: Turn On or Off the backlight.

[fn] + [-]: Decrease the backlight brightness of the keyboard.

[fn] + [=]: Increase the backlight brightness of the keyboard.

[fn] + [Z]: Slow down the running speed of backlight .

[fn] + [X]: Add up the running speed of backlight.

[fn] + [Back Space]: User's mode of backlight. Hold and press [fn] together with [Back Space] to redefine the backlight of each key. On doing so, repeatedly type the key to change its color. Hold and press [fn] together with [Back Space] once again to save the settings.

[fn] + [CapsLock]: Set the keyboard to default setting.

[fn] + [W]: 1

[fn] + [S]: 1 $[fn] + [D]: \rightarrow$

How to recharge the keyboard

Find the USB A to USB type C cable in the packaging ,plug the keyboard and connect it with computer for charging. The LED indicator Marked with "M" on the left side of the keyboard will turn to red. It will turn to white when the battery gets fully charged. Remark: The LED indicator Marked with "M" will turn to red when keyboard is out of

FAQ

- 1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
- 2. If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the ECC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

California Proposition 65

MARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure - www.P65Warnings.ca.gov





核准



Mechanical Gaming Keyboard **Operating Instructions**

型号 红龙K615P-KBS/8556 备注:尺寸:100x100mm(风琴折页) 材质:80g书写纸 名称 说明书 印刷:单黑色双面印刷 2022-2-26(修改) 日期

页码 1 OF 1 文件编号 绘图 雷国建 审核

Ш 版本 A.0

Easter Tech