

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

1

OS support

Windows XP/Vista/Win7/Win8/Win10

How to connect the keyboard with a computer

Wired Connection

1. Slide the 2.4G/OFF switch on bottom of the keyboard to OFF.
2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer, computer will recognize and configure the keyboard automatically.
3. Once the keyboard is powered up, charging begins. The LED marked with M lights on red. It will turn to green when keyboard is fully recharged.

2.4G Wireless Connection

1. Slide the 2.4G/OFF switch on bottom of the keyboard to 2.4G.
2. press [FN]+[R] for about 3 seconds, the LED marked with M flashes quickly in yellow, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically.
3. The indicator will flash on Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to Green when charging completed(In 2.4g connecting mode)

Function Introduction

1. With standard USB and 2.4G connections, the keyboard can be used on computer without any software or driver installation.
2. There are 20 backlight effects.

2

3. Commands of key combinations with [FN] key

- [FN]+[R-Alt]: Change backlight mode. There are 20 backlight effects.
- [FN]+[Space bar]: Change back light color.
- [FN] + [Backspace]: Turn On or Off the backlight.
- [FN] + [←]: Slow down the running speed of backlight.
- [FN] + [→]: Add up the running speed of backlight.
- [FN] + [↑]: Increase the backlight brightness of the keyboard.
- [FN] + [↓]: Decrease the backlight brightness of the keyboard.
- [FN] + [Win]: Disable or enable the [Win] key.
- [FN] + [R]: Change to 2.4G wireless connection.
- [FN] + [TAB]: Set the keyboard to default setting.

Multi-media keys function

- FN+ESC= `
- FN+Shift+ESC= ~
- FN+(1)=F1
- FN+(2@)=F2
- FN+(3#)=F3
- FN+(4\$)=F4
- FN+(5%)=F5
- FN+(6^)=F6
- FN+(7&)=F7
- FN+(8*)=F8
- FN+(9)=F9
- FN+(0)=F10
- FN+(-_)=F11
- FN+(=+)=F12
- FN+P=PRTSC

3

- FN+([)=SCRLK
- FN+(])=PAUSE
- FN+L=INS
- FN+(;)=HOME
- FN+(")=END
- FN+(,<)=DEL
- FN+(.>)=PGUP
- FN+(/)=PGDN
- FN+(RIGHT)CTRL=APP
- FN+(+)=*
- FN+(-)=/
- FN+Z=Volume-
- FN+X=Volume+
- FN+C=mute
- FN+V=Stop
- FN+B=Previous track
- FN+N=Pause/Play
- FN+M=Next track

How to recharge the keyboard

Find the USB A to USB type C cable in the packaging, plug the keyboard and connect it with computer for charging, the LED indicator(M) of keyboard will be turn to green. Remark: The LED indicator (M) will turn to red when keyboard is out of battery.

 Warning: Charging Input: 5V=1A

4

FAQ

1. If the keyboard doesn't respond, please check if the keyboard's USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please remove keyboard's USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.



5

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

6



REDRAGON

ZED PRO

WIRELESS MECHANICAL GAMING KEYBOARD

Mechanical Gaming Keyboard Operating Instructions

型号	红龙K627P-KNS/8655	备注：尺寸：100x100mm (折页)	
名称	说明书	材质：80g书写纸	
日期	2022-2-22(修改)	印刷：单黑色双面印刷	
页码	1 OF 1	文件编号	
绘图	雷国建	审核	
		核准	
		版本	A.0