US UK

Dear user

Thank you for choosing **REDRAGON** product. To protect your rights and for better customer service, please read the following warranty rules carefully.

- 1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
- 2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

OS support

Windows XP/Vista/Win7/Win8/Win10

How to Charge keyboard

Find the USB A to USB type-C cable in the package, plug the keyboard and connect it with computer for charging, the LED "M" indicator of the keyboard will turn to red. Remark: The LED "M" indicator will flash in red when the keyboard is short of power.

Marning: Charging Input: 5V ===1A

How to connect the keyboard with device

1. Wired Connection

- 1.1 Slide the ON/OFF switch to OFF
- 1.2 Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer.
- 1.3 The computer will recognize and configure the keyboard automatically.
- 1.4 The keyboard will be ready for use when the configuration is finished.

2. 2.4G Wireless Connection

- 2.1 Slide the ON/OFF switch to ON
- 2.2 Turn on the keyboard and press [FN]+[RF] for about 3 seconds, the LED M flashes in green, plug the USB receiver into any available USB port on your computer within 20 seconds. The keyboard will be paired automatically. Make sure the keyboard has enough power before doing so.
- 2.3 The keyboard will be ready for use when the configuration is finished.
- 2.4 The indicator will flash when the battery is low. Please recharge the keyboard in time or it will turn off automatically soon.

2

3. Bluetooth Connection

- 3.1 Slide the ON/OFF switch to ON.
- 3.2 Press [FN]+[BT1](or [BT2]/[BT3] for other Bluetooth devices), the LED M flashes in blue (or cyan/pink for the others)
- 3.3 Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0KB or BT5.0 KB" device. Select it and it will connect automatically.

Function Introduction

- 1. Brightness adjustment: Press and hold the [FN] key, and then press the arrow key "↑" or "\" to increase or decrease the backlight brightness of the keyboard.
- 2. Adjustable lighting speed: Press FN+ [\leftarrow] or [\rightarrow] to decrease or increase lighting effect speed
- 3. To lock or unlock the [WIN] key: FN+ Win_L, repeat to lock or unlock.
- 4. There are 6 pre-set backlight patterns,
- 1) FN+INS : Specture
- 2) FN+DEL:Neon
- 3) FN+HOME: Steady ON lighting switch in 7 colors
- 4) FN+PGUP: Steady ON lighting in Red, Green, Blue mixed color
- 5) FN+PGDN: Click to trigger the light
- 6) FN+END: Breathing
- 5. Back to factory setting: FN+ESC
- 6. Multimedia function: 12 multimedia keys

- <7>FN + F7= Play/Pause <8>FN + F8=Next Track <9>FN + F9= Mail
- <10>FN + F10= Web/Home <11>FN + F11= Computer <12>FN + F12= Search

3

FAQ

- 1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on
- 2. If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

5







Wireless /wired RGB Gaming keyboard Operating Instructions



型号 | 红龙K509P-WS/8668 | 备注:尺寸:100x100mm (折页) 材质:80g书写纸 说明书 名称 印刷:单黑色双面印刷 2021-11-18(修改) 日期 页码 1 OF 1 文件编号 绘图 雷国建 审核 核准

版本 A.0