

XD DESIGN

Project - XR15
SKU -
Dieline - XR15 Voice Remote GSG
Date - April 16, 2018

Color - Pantone 299C, 4 color process
Material - 100#
Finish - Matte Film both sides



351.79 mm

Getting Started Guide

Everything you need to set up your new Xfinity voice remote

How it works

- TV input**
Switches to the next available input on your TV.
- Mic/Status LED**
- Power**
- Record**
Starts recording the program you're watching or saves future programs to your DVR.
- Xfinity/menu**
Access search and settings, Xfinity On Demand, saved programs, apps, and the Guide.
- Back arrow**
Press and release for Last.
- Info**
Displays information about programs and notifications.
- Voice control**
Use voice commands to search for networks, shows, set DVR recordings, and get recommendations. Use keywords, say a network name, or ask for a specific program.
- Number keys**
Use predictive text (T9) to quickly search for content.

Setting it up

- 1 Set up your TV**
Turn on your TV and TV box.
- 2 Activate your remote**
Your voice remote arrives with 2 AA batteries installed. Activate the remote by removing the "Pull" tab on the back.
- 3 Wait for the LED light**
The status LED light will blink blue 3 times as your voice remote powers up. This should take about 5 seconds.
- 4 Select the voice button**
Press the voice button while pointing at the TV Box. Follow the on-screen prompts to complete setup.
- 5 Try a voice command**
Now that your voice remote is paired, press and hold the voice button and ask, "What can I say?" for suggestions—or say "Remote help" to see tips and tricks.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase or decrease the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the place of purchase or an experienced remote control/TV technician for help.
- It is strongly recommended that the TV be plugged into a separate wall outlet.

The user is cautioned that changes and modifications made to this equipment without the approval of the manufacturer could void the user's authority to operate this equipment. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Need help? We're here.
Watch videos, search FAQs, and more at: xfinity.com/selfinstall
We speak your language.
For English and Spanish, give us a call at: **1-800-XFINITY**
For Chinese, Korean, Vietnamese, or Tagalog: **1-855-955-2212**

152.146 mm

Front

Guía de inicio

Todo lo que necesitas para instalar tu nuevo Control Remoto por voz de Xfinity

Cómo funciona

- TV input**
Cambia a la siguiente entrada disponible en tu televisor.
- Mic/LED de estado**
- Power**
Enciende y apaga el televisor.
- Grabar**
Empieza a grabar el programa que estás viendo o graba programas futuros en tu DVR.
- Xfinity/menu**
Accede a las secciones de buscar y configuraciones, Xfinity On Demand, programas grabados, apps y la Guía.
- Flecha atrás**
Presiona y suelta para ir a lo anterior.
- Info**
Muestra información sobre programas y notificaciones.
- Control por voz**
Usa comandos de voz para buscar cadenas o shows, programar grabaciones en tu DVR y obtener recomendaciones. Usa palabras claves, el nombre de la red, o pregunta por un programa específico.
- Teclas de números**
Usa texto predictivo (T9) para buscar contenido rápidamente.

Vamos a configurarlo

- 1 Configura tu televisor**
Enciende tu televisor y decodificador.
- 2 Activa tu control remoto**
Tu control remoto por voz viene con 2 baterías AA ya instaladas. Activa el control remoto quitando la pestaña de "Pull" de la parte trasera.
- 3 Espera por la luz LED**
La luz LED de estado parpadeará en verde 3 veces mientras se enciende tu Control Remoto por voz. Esto debería de tardar alrededor de 5 segundos.
- 4 Selecciona el botón de voz**
Presiona el botón de voz mientras apuntas al decodificador. Sigue las indicaciones que aparecen en pantalla para terminar la configuración.
- 5 Prueba un comando de voz**
Ahora que tu control remoto por voz está conectado, mantén presionado el botón de voz y pregunta "¿qué puedo decir?", para ver sugerencias, o di "Ayuda" para ver consejos.

Declaración de conformidad de la FCC

Este equipo se ha examinado y se ha comprobado que cumple con los límites establecidos para un equipo digital de clase B, conforme a la parte 15 de las reglas de FCC. Estos límites se diseñaron para proporcionar una protección razonable contra interferencias perjudiciales en una instalación residencial. Este equipo genera, usa y puede emitir energía de radiofrecuencia y, si no se usa de acuerdo con las instrucciones, puede causar interferencias perjudiciales a las comunicaciones de radio. No hay ninguna garantía de que la interferencia no ocurrirá en una instalación en particular. Si este equipo causa interferencias perjudiciales a la recepción de la radio o la televisión, se anima al usuario a que intente corregir la interferencia de una o más de las formas ofrecidas a continuación:

- Reorientar o reubicar la antena receptora.
- Aumentar o disminuir la separación entre el equipo y el receptor.
- Conectar el equipo a un enchufe en un circuito diferente al que esté conectado el receptor.
- Pedir asistencia en el lugar de compra o a un técnico de TV y/o controles remotos experimentado.
- Es sumamente recomendable que la TV esté enchufada a una conexión de la pared separada.

Se advierte a los usuarios que los cambios y modificaciones que se hagan a este equipo sin la aprobación del fabricante podrían invalidar la autoridad del usuario para manejar este equipo. Este equipo se ajusta a la parte 15 de las reglas de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes: (1) Este equipo no puede causar interferencias perjudiciales y (2) este equipo debe aceptar cualquier interferencia recibida, incluso la que pueda causar un funcionamiento indeseado.

¿Necesitas ayuda? Estamos aquí.
Ve videos, consulta la sección de preguntas frecuentes y más en: es.xfinity.com/selfinstall
Hablamos tu idioma.
Para inglés y español, llámanos al: **1-800-XFINITY**
Para chino, coreano, vietnamita o tagalo: **1-855-955-2212**

Back