

#### 4.6. Test Photograph

Test Mode : Mode 1: Normal Operation (WPT)

Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 1: Normal Operation (WPT)

Description : Back View of Radiated Emission Test Setup



**5. Attachment**

➤ **EUT Photograph**

(1) EUT Photo



(2) EUT Photo



(3) EUT Photo



(4) EUT Photo



(5) EUT Photo





(6) EUT Photo (Adapter: EDAC, EA10681U-120)



(7) EUT Photo



(8) EUT Photo

