



Hi Andy,

Good day to you.

The frequency range we applied is 5150MHz-5350Mhz and 5470MHz-5725MHz. Form731 requires to fill in the highest and lowest channel frequency .But we can only fill one band in the Form 731, so how can we fill both two band in to the form with one blank for one band? Now, the form731 can not be changed ,could you tell me what shall we do ?

Thank you very much.