


TEST SETUP FOR EMISSIONS TESTING

TUV PRODUCT SERVICE Medium Test Site

Notes:

1. Items shown in dotted lines are located on the floor below the test area. It is 5 meters vertically from the ground floor to test area.
2. 50 Hz and 60 Hz are power panels for alternating current.
3. The antenna may be positioned horizontally 3 or 10 meters from the center of the turntable.
4. The circle is a 6.7 meter diameter turntable.
5. A ground plane is in the plane of this sheet.
6. The test sample is shown in the azimuthal position representing zero degrees.



Test-setup photo(s):
General Field Strength Limits 0.009 – 30 MHz




Test-setup photo(s):
Radiated Emissions 30 - 1000 MHz



Test-setup photo(s):
Radiated Emissions 30 - 1000 MHz



Test-setup photo(s):
Conducted Emissions, AC lines, 150 kHz - 30 MHz



Test-setup photo(s):
Radiated Emissions, above 1000 MHz

