

ALL-TERRAIN RACE CAR

PISTOL GRIP -

BATTERY COMPARTMENT -

SAFETY PRECAUTIONS

• Do not operate during thunderstorms or rain.

Do not submerge car or controller in water.

the car is switched to "ON".

long periods of time.

Avoid water, sand and snow when operating car.

Never operate your car on the street or highway.

• Adult supervision is recommended when operating this car.

and use to reduce the risk of electrical shock.

BATTERY INSTALLATION

Carefully remove items from package.

cover and connect the battery pack. Replace the battery compartment door.

Replace the battery compartment door.

STEERING ALIGNMENT ADJUSTMENT:

To fine-tune the steering control, locate the alignment

switch on the underside of the chassis. Starting with

the lever in the middle position, test drive your car and adjust as needed. Should the car pull to the left or right, simply move the lever until your car drives

Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
Insert batteries using the correct polarity. Do not short-circuit the supply terminal.

Always use, replace, and recharge (if applicable) batteries under adult supervision.

Remove batteries downen not in use. Recycle or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire - they may leak or explode.
 Only use manufacture specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

rights reserved.

ENT PENDING

D2017 Sharper Image. Sharper Image® name and logo are registered trademarks.

ibuted by MerchSource, LLC. Irvine, CA 92618.

technical support, please call 1-800-374-2744.

straight without touching the directional controller.

BATTERY WARNING: Do not mix old and new batteries.

Made in China

Operation requires one NiMH rechargeable battery pack (included) for car and one 9V battery (included) for radio controller.

Locate the battery compartment on the bottom of the vehicle.

Loosen the screw on the bottom of the car to open the battery

Slide open the battery compartment door of the controller.

Insert the one 9V battery following the correct polarity.