

# **GD88BT Portable Speaker With Bluetooth**

## **Quick Start Guide**

# GD88BT Quick Start Guide

---

## Fcc information

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- 

-----

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Disclaimer

All the information, design and specifications contained in this manual were correct at the time of publication. However, as the product is under continuously upgrading, the final device may have a slightly difference in appearance or modified functionality than presented in this manual.

## Safety precautions

- Never subject speaker to extremes of light, temperature, moisture or vibration.
- Do not use or store speaker in a location subject:
  - A. Extreme high temperature, such as in a sun-heated car
  - B. Direct sunlight
  - C. High humidity or places with corrosive substances
  - D. Sub-zero condition, especially during winter.
- Clean only with a dry cloth.
- Don't block any of the ventilation openings, install according to the manufacturer's instructions.
- Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way.




The symbol means that the unit complies with European safety and electrical interference directives.


# GD88BT Quick Start Guide






## Parts and Control

Side View



Top View



1. **USB jack** - for connecting to music source or emergency charging.
2. **Line-in port** - to connect to external audio device via 3.5mm audio cable
3. **Power button** - Press and hold to turn the device on or off. Press once briefly to play/pause audio playback when connected to Bluetooth device.
- 4,5. **+/- Volume button** - Press and hold to adjust the volume level;
6.  **Pairing button**- Press to enter bluetooth mode
7.  **LED indicator for Line-in mode**
- 8,10.  **Previous/Next song button**- During music playback in bluetooth mode, press to go to previous/next song.
9.  **Play/Pause button**- During music playback in bluetooth mode, press to play/pause.
11.  **LED indicator for Charging/Pairing**

# GD88BT Quick Start Guide


---

## Getting Started

Carefully remove the speaker from packet.



## Charging

When battery power is low, charge the speaker by connecting GD88BT to a computer or USB power adapter via the supplied USB cable.

The red LED indicator on  will light on, indicating that it is on charging mode.


The red LED indicator on  will turn off when fully charged.

## Turning on/ off the speaker

- To turn on the Portable Speaker, press and hold the **Power** button for about 3 seconds until the LED indicator  lights on
- To turn off the portable speaker, press and hold the **Power** button for about 3 seconds to turn off the speaker until the LED indicator  turns off.

## Playing music



Please follow the below steps to play music.


1. Plug the connector to the music source, e.g. PCs/laptops, MP3 players or radios.
2. Turn on the Portable Speaker, then the red LED indicator on  will light on.
3. Start playing the selected music or radio from the music source.
4. Press the **+/- Volume** button to increase or decrease the volume level.





## GD88BT Quick Start Guide

---

### Setting Bluetooth mode

1. Turn on the Portable Speaker and exit from Line-in mode to enter bluetooth mode, then the red LED indicator on  will turn off and the blue LED indicator on  will blink.
2. The bluetooth device of music source will search for GD88BT speaker, then select the "GD88BT" and pair the GD88BT speaker with the Bluetooth device.

**Note:** when the speaker is connected to bluetooth device, the blue LED indicator on  will always light on.

3. Start playing the selected music or radio from the music source.
4. Press the  /  button to go to next/previous song.
5. Press the  button to play/pause the music playback.
6. Press the **+/- Volume** button to increase or decrease the volume level.
7. Press the Pairing button  to exit from bluetooth mode.

**Note:** If there is no response on the speaker, press the **Reset** button at the bottom of the speaker.