

Hardware description

The player comes with

1. 6 control buttons
 - a. One on the line of the stereo earphones – PLAY button
 - b. 5 buttons on the player – UP/DOWN, NEXT/PREV and STOP
2. 1 3.5mm headphone jack hidden under the rubber stopper.
3. 1 hidden RESET button placed behind the 3.5mm headphone jack
4. 1 Mic on the line of the stereo earphones
5. LED indicator (red & blue 2 colours) on top of the front surface of the player
6. The picture below indicates the position of each part as described above

Operation Manual

1. Button events vs Corresponding Actions

Buttons	Events	Actions
PLAY	PR	1. Power On when it is at standby 2. Play/Pause while playing 3. Pick up phone when there's incoming call.
PLAY	PH<5sec	Give Battery level indication
PLAY	PH>5sec	Enter Pairing Mode
STOP	PR	1. Stop music while playing 2. Reject an incoming call or hang up the call.
STOP	PH<5sec	Change playmode (Normal ⇔ Random)
STOP	PH>5sec	Shutdown
PREV	PR	Previous song
PREV	PH	Rewind
NEXT	PR	Next song
NEXT	PH	Fast Forward
UP	PR or PH	Volume Up
DOWN	PR or PH	Volume Down

Note: PR = Press and Release
PH = Press and Hold

2. LED Indicator

State	LED status
Playing with battery >30%	Blue LED blink every 10 sec
Playing with battery <30%	Red LED blink every 10 sec
During Pairing	Blue and Red alternating very quickly
During USB read and write	Blue and Red alternating moderately
During USB idle with battery >30%	Blue LED blink moderately
During USB idle with battery <30%	Red LED blink moderately
During Charging with battery >30%	Blue LED blink moderately
During Charging with battery <30%	Red LED blink moderately
After fully charged	Blue LED blink very quickly

3. General Operations

- a. Turn on the player
 - i. Press and release PLAY to turn on the player
 - ii. The player takes about 3 sec to start up depends on the number of songs stored inside.
 - iii. Once it is started, you will hear a welcome message "Enjoy your Bluetooth Headset with Music!"
- b. Playing music
 - i. Normal playing operations
 - 1. Please refer to the "Button events vs Corresponding Actions" table.
 - ii. Change play mode
 - 1. Press and hold STOP button for about 1 sec then release and you will hear the selected playmode, that is "Normal" or "Random".
- c. Use as a Bluetooth Headset
 - i. Pair with Hand phone
 - 1. Press and hold the PLAY button until you hear the message "Enter Pairing..."
 - 2. Use your hand phone to look for this Device (Snafu-Clip)
 - 3. Once it is found, select this device and key in the password: "0000".
 - 4. Once it is pair successful, there will be a message "Pair Success!"
 - 5. If failed to pair within the pairing period of 60sec, there will be a message "Pair Failed!"
 - 6. To disconnect, press and hold STOP to shutdown the player
 - ii. Answer incoming call
 - 1. Press and release PLAY button
 - iii. Reject incoming call
 - 1. Press and release STOP button
 - iv. Stop a call session
 - 1. Press and release STOP button
- d. Shutdown the player
 - i. Press and hold the STOP button until you hear the shutdown message "See you again..."
- e. Reset the player
 - i. Use the RESET button only when the player is hang.
- f. Use as USB drive
 - i. Use the USB cable provided to connect to computer and it will be recognized as a USB Mass Storage Class and it can be found in "My Computer"
- g. Charging the player
 - i. Use the USB charger provided to charge the player.
 - ii. Charge until the Blue LED blinking very quickly.