

# TPMS


## TX-V003/TX-V004 User's Manual

Frequency	315/433.92 MHz
Pressure Range	100~900 kPa
Temperature Range	-40 ~125°C
Operating Humidity	Max. 95%
Operating Temperature	-40 ~105°C
Storage Temperature	-40 ~125°C

(1) Dismount tire and sensor from the wheel. And clear valve stem hole in rim of  
Dismount tire and sensor from the wheel.



Push the valve stem thru the rim, install the washer and nut, then tighten the nut to  
36 in-lb



Hold the sensor body against the rim and install then tighten the screw to 20 in-lb

Mount the tire back to vehicle



**FCC Notices**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION:**

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

**RF exposure warning:**

The equipment complies with FCC RF exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.