


Welcome to AMGOO




Please note

All the functions in this manual should be operated in **Standby Mode**.

Like the picture below.

Tips:

Press **END** go back to the **Standby Mode**



(Standby Mode)

Make a call

Input the numbers, Press **Send1**

Answer a Call.

Press the **Send1**


Tips:

***Left Key** to volume down..

***Right Key** to volume up.

*To unlock the keypad **Left Soft**

Key>*



Call logs

OK>**OK**

OK>**OK**

Dialed Calls

OK>**OK**>2

Display your recent dialed numbers.

Received Calls

OK>**OK**>3

Display your recent answered numbers.

Missed Calls

OK>**OK**>1

Display your recent missed numbers.

Delete call logs

Delete All

OK>**OK**>4


You could delete all the records of the Dialed,

Received, Missed and Rejected.

Call settings

Calculator

Press **OK**>**OK**>6>**OK**



OK>**OK**>**OK**>

Set the call option

auto redial

OK>**OK**>2 >1>1

Automatic redial Settings

Call time reminder


OK>**OK**>2 >1>2

Set the call time reminder

Answer mode

OK>**OK**>2 >1>3

Set the telephone answering mode.



Settings

You can customize the settings, such as time and date, language, call settings etc.

Tips:

Press **OK**>**OK**>**OK**



Contacts

To browse the name card holder, store, edit and delete the names and phone numbers in the phone and SIM card.

Tips:

OK>**OK**>**OK**>


Options>New

To Edit

Choose the contact>Options>Edit

To Delete

Choose the contact>Options>Delete



Message

To receive and send the message.

Press **Left Key**

Write Message

To write new message.

In box

Store the SMS and Push message

Out box

Store the SMS you've sent in failure.

Drafts

Store the SMS you've edited.

Sent box

Store the SMS you've sent successfully.

Tip: Press # to select the desired input methods

Press * to input symbols



OVERVIEW

Multimedia

FM Radio


Please connect with the earphone You can listen to Fm radio freely.

OK>**OK**>**OK**>FM radio

Tip: For the performance Multimedia function please insert the T-flash card.

***Key** to volume down..

Right Key to volume up.




Camera

The device is equipped with a webcam with high pixels. You can take photo at any time.

Press **OK**>**OK**>**OK**>**OK**

Press ok to take the picture



Internet

The device is compatible with WAP service. You can visit news, weather forecast and airlines etc.

Press **OK**>**OK**>**OK**

*Depends on network support.



Thank you!

CAUTION!

"Using the wrong type of battery, there is a danger of explosion."



"Must be in accordance with the disposal of used batteries."

Ring settings:

Right key>Choose the profiles.

To customize the ring settings

options>customize>ring settings.



Bienvenido a AMGOO



Empezar Aquí

Visión General

Multimedia

Radio FM


Por favor, conecte los audifonos para que pueda escuchar la radio FM libremente.

OK > > Radio FM

Consejos: Para mayor desempeño de la funcion multimedia insertar la memoria Micro-SD.

Tecla *: Para bajar el volumen.

Tecla #: Para subir el volumen.




Por favor tenga en cuenta

Todas las funciones en este manual deben ser operadas en modo de espera.

Como se muestra en la imagen de abajo.

Consejos:

Presione **Finalizar** para regresar al modo de espera



(Modo de espera)

Camara

El teléfono viene equipado con una Cámara. Puede tomar fotos en cualquier momento.

Presione OK > > OK > OK

Presione OK para tomar la foto



Hacer una llamada

Introduzca los numeros y Presione la tecla **Llamar**

Contestar una llamada

Presione la tecla **Llamar**

Consejos:

***Tecla izquierda**: Bajar el volumen.

***Tecla derecha**: Subir el volumen.

*Para desbloquear el teclado presionar la tecla **Izquierda** > *




Internet

El teléfono es compatible con el servicio WAP. Puede ver las noticias, el pronóstico del tiempo, aerolíneas, etc.

Presione OK > > OK

***Depende del soporte de la red.**



Registro de llamadas

OK > > OK

Llamadas echas

OK > > OK > 2

Muestra los numeros marcados recientes.

Llamadas recibidas

OK > > OK > 3

Muestra las llamadas contestadas recientes.

Llamadas perdidas

OK > > OK > 1

Muestra las llamadas perdidas.

Eliminar registros de llamadas


Borrar todo

OK > > OK > 4

Puede eliminar todos los registros de llamadas Echas, perdidas, y recibidas.

Ajuste de llamada

OK > > OK >



Llamada automatica

OK > > 2 > 2 > 1

Activar/Desactivar la llamada automatica

Aviso de hora de llamada


OK > > 2 > 2 > 2

Establecer el tiempo de recordatorio en llamada.

Modo de respuesta

OK > > 2 > 1 > 3

Seleccione el modo de contestar la llamada.




Configuracion

Puede editar la configuración, como el día y la hora, el idioma, la configuración de las llamadas, etc.

Consejos:

Presione OK > > OK



Contactos

Para ver los contactos y números de teléfono, guardarlos, editarlos y borrarlos en el teléfono y en la tarjeta SIM.

Consejos:

OK > > OK >

Agregar un contacto


Opciones > Nuevo

Para editar

Seleccione el contacto > Opciones > Editar

Para Borrar



Seleccione el contacto > Opciones > Borrar



Configuracion de tono:

Tecla derecha > Seleccionar los perfiles.

Para personalizar los tonos > Personalizar > Configuración de llamada.



Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.5 cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.